


## **Motorcontroller CO-Series**

### **User's Manual**

### **Version 1.28e**



**Calantec GmbH** Automatisierungstechnik, Industrieelektronik

Aufgang B  
Helmholtzstraße 2-9  
10587 Berlin  
<http://www.calantec.de>

Telefon: 030 453 01 519  
Telefax: 030 453 01 531  
email: [info@calantec.de](mailto:info@calantec.de)

Geschäftsführer:  
Handelsregister:  
USt-ID:

Hartmut Schäfer  
Amtsgericht Charlottenburg HRB 92065  
DE232787423

valid for software version 016.031 and higher  
Controller CO2200, CO4200, CO4300, CO6100, CO6150,  
CO6300, CO6500, CO5400, CO5500

H. Schäfer 2006-12-18

## Table of Contents

<b>1. Start Up.....</b>	<b>4</b>
Axis configuration.....	4
PID parameters.....	4
Group configuration.....	5
CONFIG.SYS.....	5
Properties of the FLASH and EEPROM disc.....	6
BASIC interpreter.....	6
Program example.....	6
BIOS update.....	7
<b>2. Command Reference.....</b>	<b>8</b>
BASIC-Commands and Functions.....	8
Motor control commands.....	42
<b>3. Appendix A: G-Codes.....</b>	<b>63</b>
Standard-G-Codes.....	63
<b>4. Appendix B: Programming hints for special hardware.....</b>	<b>72</b>
Programming of microstepping controllers:.....	72
Programming hints for CO6300.....	72
Amplifier PW2000.....	73
Jogdial programming.....	74
<b>5. Appendix C: Inputs and outputs.....</b>	<b>76</b>
Inputs.....	76
Outputs.....	77
<b>6. Appendix D: ASCII code table.....</b>	<b>78</b>
<b>7. Appendix E: Pinouts.....</b>	<b>79</b>
<b>8. Appendix F: Pin description.....</b>	<b>81</b>

## 1. Start Up

The voltage of the power supply must be 24V+/-10% DC. Depending on the connected peripherals the current can be up to 2 A (amplifier current not included). The motor controller should be connected to a terminal or a computer with a terminal program running. Default serial communication parameters are 19200 baud, no parity, 8 bits, 1 stop bit, no handshake. These values can be altered with the `MODE-` command (see command reference). If the motor controller is equipped with a RS232 compatible interface (see label) you can use a standard cable, if it is equipped with a RS422 interface you have to use the converter IN232/422 or a similar RS422/RS232 converter.

### Axis configuration

The motor controller should be configured immediately after power on. The best way is to include the appropriate commands in a file named `CONFIG.SYS`. For configuration, the `MODE` and `SET` commands are used. Each of the three axes is defined either as stepper or servomotor axis and the power amplifier type is determined. Use option `PWMS` for amplifier PWM1660 and `PATTERN` for amplifier SM0435 and SM0860.

Example configuration:

```
MODE 1, PID, INC (1) , PWMS (1)
MODE 2, PID, INC (2) , PWMS (2)
MODE 3, SM, PATTERN (3)
```

Axis 1 and axis 2 are defined as servo motors, axis 3 as stepper motor. Now use `SET` commands to set necessary parameters like maximum current (`IMAX`, for stepper motors additionally standby current `ISTANDBY`). The PID algorithm for servo motor control needs the parameters `POL`, `DIFF`, `PROP` and `INT`. To determine the value of `POL` and while testing the reference movements, is it advised to limit the controller's output by setting the `MAXFORCE` parameter. Some microstepping controllers have to be programmed with the desired current profile (`WAVEFORM1`, `WAVEFORM2`).

### PID parameters

To achieve maximum velocity and accuracy PID parameter have to be set up carefully. To do this efficiently, create a text file containing all basic configuration commands:

```
MODE 1, PID, INC (1) , PWMS (1)
SET 1, IMAX, 10
SET 1, PEAK, 10
SET 1, PWMPOL, TRUE
SET 1, POL, TRUE
SET 1, MAXFORCE, 10
SET 1, PROP, 100
SET 1, INT, 0
SET 1, DIFF, 200
```

For more axes add the appropriate commands. Start with a limited controller output (`SET 1, MAXFORCE, 10` or less) and limit, if possible the amplifier current (`SET`

1, MAXFORCE, 10). Now switch on the controller with `MOTOR 1 ON`. If the motor axis is now moved, it will either move back to the former position (which is right) or run continuously in one direction. In the latter case change either `SET 1, POL, TRUE` to `SET 1, POL, FALSE` (resp. `FALSE` to `TRUE`), change the polarity of the motor cables or exchange incremental inputs A and B. If the control polarity is correct, increase `MAXFORCE`, `IMAX` and `IPEAK`. Now increase step by step the `PROP` parameter until the motor axis starts vibrating. Provoke the start of vibrating by hand or by using the `JUMP` command. Parameter `PROP` should be so high that the vibration stops after a while. Now increase parameter `DIFF` until the motor axis reaches the desired position with minimum overshoot. The `INT` parameter can lead to low frequency vibrating and should only be used carefully.

## Group configuration

One, two or three axes can be combined in a group by using the `GROUP` command. Linear and circular interpolation is only possible within a group. All commands for movements refer to a group.

Example:

```
GROUP 1, 1, 2, 3
```

Group 1 consists of axes 1, 2 and 3. The order of the axis numbers in the `GROUP` command determines which axis is used as X (first position), Y (second position) and Z (third position) axis.

Using the `TRAFO` command, user coordinates (for example millimeters) can be transformed into machine coordinates (i.e. so-called quadcounts, if you are using servo motors). It is also possible to correct angle errors.

## CONFIG.SYS

The commands in the file named `CONFIG.SYS` on `SID0:` are executed immediately after power-up (same execution as with `EXEC` command). This can be prohibited by pressing the `ESC` key during power-up.

To create a `CONFIG.SYS` file start the editor with `EDIT "SID0:CONFIG.SYS"` and type in the commands or transmit them using the ASCII-transfer function of a terminal program. Save file with `MENU/SAVE` and update the `FLASH` disk with the `UPDATE` command. Commands without a line number are executed directly during power-up. Commands with a line number are loaded into program memory, but not executed. They can be executed with the `RUN` command.

Example:

```
NOTAUS INTERN
MODE 1, SM, PATTERN(1)
MODE 2, SM, PATTERN(2)
SET 1, IMAX, 30
SET 2, IMAX, 30
SET 1, ISTANDBY, 20
SET 2, ISTANDBY, 20
GROUP 1, 1, 2
TRAFO 1, 534, 0, 0, 534
EXEC "PROGRAMM.SYS"
```

RUN

## Properties of the FLASH and EEPROM disc

Controllers with model names COxxxx have two internal silicon disks. The first is FLASH based and called `SID0:`, the second is EEPROM based and called `SID1:`. `SID0:` is mainly for program storage and needs the `UPDATE` command after modification. Note that all amplifiers are switched off during update. The size of `SID0:` is 256 kbytes. The built-in EEPROM disc (`SID1:`) has a capacity of 256 kbytes. It is possible to save up to 128 different files. Use the `FORMAT` command to initialize. To see the directory, use command `FILES`. Files with extension `.SYS` are not displayed. You can force their appearance with `FILES "*" .*`, 1.

## BASIC interpreter

After power-up the controller sends the character `>` (prompt) via device `STD:` (reading: keyboard and `COM1:`, writing: display and `COM1:`), if there is no autostart program as described above. Now you can type in commands which are executed immediately after the end of line (CR or CR/LF). Incoming characters are echoed to `STD:`. Corrections can be made by using the backspace key. These properties can be changed with `PROMPT`, `ECHO` and `SHELL`.

A program is created by typing (or downloading) commands with line numbers. You can check the current program with `LIST` and save it with `SAVE`. A saved program can be loaded again with `LOAD`.

It is advised to save the basic configuration (baudrate, axes, transformation etc.) in file `CONFIG.SYS` and to save the user program in a second file, for example called `AUTOEXEC.BAS`, which is executed in file `CONFIG.SYS`. Larger programs should be written with a text editor program running on a PC, and then transferred to the motor controller via serial interface (clear memory with `NEW` first). You can use the ASCII transfer function of your terminal program for this purpose and then save the program with `SAVE`.

Files without line numbers (e.g. `CONFIG.SYS`) can be copied into the EEPROM disc by first starting the controller's editor (e.g. `EDIT "SID0:CONFIG.SYS"`), then transferring the file via ASCII transfer and saving it with `MENU/SAVE`. If the file exists, clear it first with `MENU/NEW`.

## Program example

A simple BASIC program can be written, saved and executed as follows: After power-up type in the following lines:

```
>
>100 FOR i=1 to 100
>110   PRINT "HELLO"
>120   SLEEP 200
>130 NEXT
>
```

If no prompt appears, try pressing the `ESC` key during power-up and check the terminal properties and the cable. The program above can be checked with `LIST` and started with `RUN`. The program prints 100 times the word "HELLO" with a delay of 200 milliseconds. Press `ctrl-C` (ASCII code 3) to abort the program (check terminal

properties if this doesn't work).  
Save the program with

```
>SAVE "TEST.BAS"
```

The default device is EEPROM disk `SID1:.` You can get the list of files with

```
>FILES "SID1:"
```

or simply

```
>FILES
```

If you want this program to start automatically after power-up, an appropriate `CONFIG.SYS` has to be created on FLASH disk `SID0:.` Because the commands in the `CONFIG.SYS` should be executed immediately, no line numbers are necessary. For that reason the program cannot be created with the command line processor but with the editor. Call the editor program with

```
>EDIT "SID0:CONFIG.SYS"
```

Now type in the the startup commands

```
EXEC "TEST.BAS"  
RUN
```

The first line loads the program, the second starts execution. Use the text file upload function of your terminal program to transfer larger programs. Save program with **MENU/SAVE** and leave the editor with **MENU/EXIT**. Unlike `SID1:` the FLASH disk `SID0:` has to be updated with the `UPDATE` command.

```
>UPDATE "SID0:"
```

This can take several seconds. All amplifiers are switched off during this time. The program starts now automatically at the next power-up. You can get the directory of `SID0:` with

```
>FILES "SID0:",1
```

## BIOS update

The controllers BIOS can be replaced by new versions. The actual version is shown with

```
>PRINT VERSION$
```

Start BIOS update with

```
>UPDATE 12345
```

The controller acknowledges this with the numbers 1 and 2 (init phase) and waits for the update file. Upload this file with the text file upload function of the terminal program. After the complete transfer the FLASH is cleared and rewritten (phases 3,4 and 5) and the controller resets. Never interrupt the power supply during the last phases. An abort during upload is possible.

## 2. Command Reference

### Variable types:

FIX	64 bit fixpoint (32.32 format)
INTEGER	32 bit integer
STRING	string of arbitrary length
CHAR	single 8 bit character

### BASIC-Commands and Functions

#### Conventions:

a	numerical expression (integer or fix)
n	integer
nb	boolean expression
c	single character (ASCII)
s\$	string
a (n)	array
[...]	optional parameter

#### ABS

##### *Function*

Calculates the absolute value of numerical expression a. If a is a fixpoint value, the result is fixpoint, if a is integer, the result is integer.

##### **Syntax:**

a=ABS (a)

##### **Example:**

```
PRINT ABS (x)
PRINT ABS (-100.4)
```

##### **Related commands and functions:**

INT, FRAC

#### ACOS

##### *Function*

Calculates the arcuscosine of numerical expression a.

##### **Syntax:**

a=ACOS (a)

##### **Example:**

```
PRINT ACOS (x)
PRINT ACOS (0.4)
```

##### **Related commands and functions:**

SIN, COS, ASIN

#### AIN

##### *Function*

Returns the input level of analog input n. The maximum value is +100.0, minimum value ist -100.0.

##### **Syntax:**

a=AIN (n)

##### **Example:**

```
PRINT AIN (2)
```

##### **Related commands and functions:**

CALIBRATE, AOUT

<b>AOUT</b>	<p><i>Command</i></p> <p>Sets analog output <math>n</math> to level <math>a</math>. The maximum value is +100.0, minimum value ist -100.0.</p> <p><b>Syntax:</b> AOUT <math>n, a</math></p> <p><b>Example:</b> AOUT 1, 15</p> <p><b>Related commands and functions:</b> CALIBRATE, AIN</p>
<b>ASC</b>	<p><i>Function</i></p> <p>Returns the ASCII code of a character or of the first character of a string.</p> <p><b>Syntax:</b> <math>n = \text{ASC}(c)</math> <math>n = \text{ASC}(s\\$)</math></p> <p><b>Example:</b> PRINT ASC("Hallo")</p> <p><b>Related commands and functions:</b> CHR\$</p>
<b>ASHIFT</b>	<p><i>Function</i></p> <p>Returns the integer value <math>n1</math> arithmetically shifted by <math>n2</math> positions.</p> <p><b>Syntax:</b> <math>n = \text{ASHIFT}(n1, n2)</math></p> <p><b>Related commands and functions:</b> ROTATE, SHIFT</p>
<b>ASIN</b>	<p><i>Function</i></p> <p>Calculates the arcussine of numerical expression <math>a</math>.</p> <p><b>Syntax:</b> <math>a = \text{ASIN}(a)</math></p> <p><b>Example:</b> PRINT ASIN(x) PRINT ASIN(0.4)</p> <p><b>Related commands and functions:</b> SIN, COS, ACOS</p>
<b>ASSIGN</b>	<p><i>Command</i></p> <p>Assigns an input or output device to an auxiliary device (STD:, AUX1..4:). Device <math>s1\\$</math> is assign to auxiliary device <math>s2\\$</math> as input (parameter INPUT) or output (parameter OUTPUT) device. With option APPEND the device is added to existing assignments, without APPEND existing assignments are replaced.</p> <p><b>Syntax:</b> ASSIGN <math>s1\\$, s2\\$, \text{INPUT OUTPUT}[, \text{APPEND}]</math></p>

**Example:**

```
ASSIGN "DIS:", "AUX1:", OUTPUT
ASSIGN "KEY:", "AUX1:", INPUT
ECHO "AUX1:", ON
```

**Related commands and functions:**

```
OPEN, CLOSE, PRINT
```

**BEEP***Command*

**Variante 1:** Switches keyboard signal on or off.

**Syntax:**

```
BEEP ON|OFF
```

**Variante 2:** The beep signal is switched on for *n* milliseconds.

**Syntax:**

```
BEEP n
```

**Example:**

```
BEEP 500
```

**BIN\$***Function*

Returns a string which is *n2* characters long, containing the binary representation of integer expression *n1*.

**Syntax:**

```
s$=BIN$(n1, n2)
```

**Example:**

```
PRINT BIN$(123, 8)
```

**Related commands and functions:**

```
OCT$, HEX$
```

**BREAK***Command*

Switches the possibility to terminate a running program by pressing Ctrl-C (ASCII code 3) or the **STOP** key on or off.

**Syntax:**

```
BREAK ON|OFF
```

**CALIBRATE***Command*

Calibrates zero of analog output *n1* with value *n2*. If the output is not used as an amplifier control output, the calibration value is updated only at the next **AOUT** command. The calibration values can be written permanently with command **WRITEPREFS** and are then reloaded at power on.

**Syntax:**

```
CALIBRATE n1, n2
```

**Example:**

```
CALIBRATE 1, -3
```

**Related commands and functions:**

```
AOUT, WRITEPREFS
```

**CAN***Command (only with CAN hardware)*

Switches the event processing for CAN channel *n* (*n*=1..4) on or off.

**Syntax:**

CAN (n) ON|OFF

**Related commands and functions:**

ON xx GOTO|GOSUB

**CANBAUD***Command (only with CAN hardware)*

Sets the CAN baudrate of CAN interface n1 to the value n2.

**Syntax:**

CANBAUD n1, n2

**Example:**

CANBAUD 1, 125000

**Related commands and functions:**

CANID, CANERROR, CANREAD, CANWRITE

**CANERROR***Function (only with CAN hardware)*

Returns the last Error Code of CAN interface n.

**Syntax:**

n=CANERROR (n)

**Example:**

PRINT CANERROR (n)

**Related commands and functions:**

CANBAUD, CANID, CANREAD, CANWRITE

**CANID***Command (only with CAN hardware)*

Sets the identifiers for the CAN communication. Channel 0 is used for a serial communication via CAN between one master and multiple slaves. The master→slave direction uses a set of 32 identifiers (base is IDSource, identifiers are IDSource up to IDSource+31). The slave→master direction uses another set of 32 identifiers (base is IDTarget, identifiers are IDTarget up to IDTarget+31). IDSource and IDTarget must be multiples of 32. IDSource of the master and IDTarget of the slave must have identical values, as well as IDTarget of the master and IDSource of the slave.

For channels 1 to 4 the parameter ID is the CAN identifier for incoming CAN messages. Channel 1 has an optional identifier mask where zero bits are don't cares while comparing the incoming ID with the programmed ID.

With parameter mode=0, the standard identifier format (10 bit) is used, with mode=1 the extended format (29 bit).

**Syntax:**

CANID 0, mode, IDSource, IDTarget

CANID n, mode, ID[, mask]

**Example:**

CANID 0, 0, 64, 128

CANID 1, 0, 121, &amp;hfffffff0

CANID 2, 0, 34

**Related commands and functions:**

CANBAUD, CANERROR, CANREAD, CANWRITE

**CANREAD**

*Command (only with CAN hardware)*

Copies a received CAN message into `array(0)`. `n` is the channel number (1 to 4). The array must be a one-dimensional array of `char` with a size of at least 16. The entries are used as described below (`CANWRITE`), they don't have to be initialized. Entry 16 is set to `&hff`, if a new message was received, and set to 0 if not.

**Syntax:**

```
CANREAD n,array(0)
```

**Example:**

```
DIM candata(16) AS CHAR
CANREAD 1,candata(0)
```

**Related commands and functions:**

`CANBAUD`, `CANERROR`, `CANID`, `CANWRITE`

**CANWRITE**

*Command (only with CAN hardware)*

Sends a CAN message defined in `array(0)` via CAN interface `n`. The array must be a one-dimensional array of `char` with a size of at least 16. The entries have to be initialized as follows:

<code>array(1)</code>	Identifier, most significant byte
<code>array(2)</code>	Identifier, second most significant byte
<code>array(3)</code>	Identifier, third most significant byte
<code>array(4)</code>	Identifier, least significant byte
<code>array(5)</code>	data byte 0
<code>array(6)</code>	data byte 1
<code>array(7)</code>	data byte 2
<code>array(8)</code>	data byte 3
<code>array(9)</code>	data byte 4
<code>array(10)</code>	data byte 5
<code>array(11)</code>	data byte 6
<code>array(12)</code>	data byte 7
<code>array(13)</code>	reserved
<code>array(14)</code>	number of data bytes
<code>array(15)</code>	mode (0=standard, 1=extended)
<code>array(16)</code>	reserved

The standard mode (`mode=0`) uses 10 bit identifiers, the extended mode (`mode=1`) uses 29 bit identifiers.

**Syntax:**

```
CANWRITE n,array(0)
```

**Example:**

```
DIM candata(16) AS CHAR
candata(1)=0      :' ID MSB
candata(2)=0      :'
candata(3)=0      :'
candata(4)=20     :' ID LSB
candata(5)="A"    :' CAN Data 1
candata(6)="B"    :' CAN Data 2
```

```
candata(7)="C"  :' CAN Data 3
candata(14)=3   :' CAN Length
candata(15)=0   :' CAN Mode
CANWRITE 1,candata(0)
```

**Related commands and functions:**

CANBAUD, CANERROR, CANID, CANREAD

**CASE***Command*

See SELECT .. CASE.

**CHR\$***Function*

Returns a string consisting of one character with ASCII code n.

**Syntax:**

s\$=CHR\$(n)

**Example:**

```
PRINT CHR$(65)
```

**Related commands and functions:**

ASC

**CINT***Function*

Numerical expression a is rounded to an integer.

**Syntax:**

n=CINT(a)

**Example:**

```
PRINT CINT(65.6)
```

**Related commands and functions:**

ABS, FRAC, INT, FIX

**CLEAR***Command*

The event processing is switched off (if not prevented earlier with CONTEVENTS ON), unused variables are discarded, open files are closed. Used variables are set to default values.

**Syntax:**

```
CLEAR
```

**Related commands and functions:**

CONTEVENTS, NEW

**CLEARBUF***Command*

The input buffer of channel n is cleared.

**Syntax:**

```
CLEARBUF n
```

**Related commands and functions:**

OPEN, INPUT

**CLEARSTACK***Command*

Clears BASIC stack.

**Syntax:**

```
CLEARSTACK
```

**Related commands and functions:**

POPSTACK

**CLOSE***Command*

Closes one or more open files.

**Syntax:**

CLOSE [[#]n1][, [#]n2]...

**Example:**

CLOSE

CLOSE #1, #2

**Related commands and functions:**

OPEN

**CLS***Command (with display only)*

The display is cleared, the cursor is set to the upper left corner and is switched on.

**Syntax:**

CLS

**Related commands and functions:**

LOCATE, CURSOR

**CODE (C)***Function*

Returns the ASCII code of the last pressed function key.

**Syntax:**

a=CODE (C)

**Example:**

PRINT CODE (C)

**Related commands and functions:**

CTRLCODE, ON xx GOTO/GOSUB

**COM***Command*The event processing for serial interface *n* is switched on or off. The option COM(*n*) STOP stops event processing, but all appearing events are processed after switching event processing on.**Syntax:**COM(*n*) ON|OFF|STOP**Related commands and functions:**

ON xx GOTO|GOSUB

**CONNECT***Command*Connects a slave controller to a master controller via the given communication interface. The communication interface is assigned the number *n* which is used to change the slave controller (see NETMASTER command). *n* can be between 1 and 31.**Syntax:**CONNECT *n*, *s*\$**Example:**

CONNECT 1, "COM1:"

CONNECT 2, "CAN1:3"

**Related commands and functions:**

NETMASTER, NETSLAVE

**CONTEVENTS**

*Command*

Switches event processing after finishing a program on or off. If it is switched on, events like `TIMER`, `COM` and `CAN` are still processed (i.e. the interpreter jumps in the given program line), even if the main program is finished. If the program is altered the system may crash, so it is strongly advised to use the `NEWLIST` command.

**Syntax:**

CONTEVENTS ON|OFF

**Related commands and functions:**

CLEAR, NEW, ON xx GOTO|GOSUB

**CONTRAST**

*Command (with display only)*

Adjusts LCD contrast. Values between -10 and 10 change contrast relatively, values larger than 10 set the contrast absolute. Maximum value is 100. The contrast value can be written permanently with command `WRITEPREFS` and is then reloaded at power on.

**Syntax:**

CONTRAST n

**Example:**

CONTRAST -2

CONTRAST 70

**Related commands and functions:**

WRITEPREFS

**COS**

*Function*

Calculates the cosine of numerical expression a.

**Syntax:**

a=COS (a)

**Example:**

PRINT COS (x)

PRINT COS (0.4)

**Related commands and functions:**

ACOS, ASIN, SIN

**CTRLCODE**

*Command (with keyboard only)*

Switches event processing for function keys on or off. The ASCII code of the last pressed function code can be read with function `CODE (C)`.

Key	ASCII code
STOP	3
HALT	4
EDIT	5

<b>START</b>	6
<b>RUN</b>	7
<b>MENU</b>	14
<b>MOVE</b>	15
<b>STEP</b>	16
<b>REF</b>	18
<b>TEACH</b>	20
<b>ESC</b>	27

**Syntax:**

CTRLCODE ON|OFF

**Related commands and functions:**

ON xx GOTO|GOSUB, CODE

**CURSOR***Command (with display only)*

Switches cursor on or off.

**Syntax:**

CURSOR ON|OFF

**Related commands and functions:**

CLS, LOCATE

**DELETE***Command*

Deletes a file named s\$.

**Syntax:**

DELETE s\$

**Example:**

DELETE "TEST1.BAS"

**Related commands and functions:**

OPEN, FORMAT

**DIM***Command*

Declares and sets the size of an array. The indices n1, n2 and n3 are the sizes of the array. Allowed variable types are INTEGER, FIX, CHAR and STRING.

**Syntax:**

DIM array(n1[,n2[,n3]]) AS INTEGER

DIM array(n1[,n2[,n3]]) AS FIX

DIM array(n1[,n2[,n3]]) AS CHAR

DIM array(n1[,n2[,n3]]) AS STRING

**Example:**

DIM xcoord(100) AS FIX

DIM men1(5) AS STRING

DIM data(64,64,64) AS FIX

**DO . . LOOP***Command*

Repeats a block of command as long as a condition is true (WHILE a) or until a condition is true (UNTIL a). The condition check is performed where WHILE und UNTIL are positioned, either at the beginning or at the end of the block

of commands. Expression *a* is `TRUE`, if it is not equal zero, it is `FALSE`, if it is zero.

**Syntax:**

```
DO [WHILE | UNTIL a]
    [block of commands]
LOOP [WHILE | UNTIL a]
```

**Example:**

```
x=1
DO WHILE x<10
    x=x+1: PRINT x
LOOP
```

**Related commands and functions:**

EXIT, FOR..NEXT

**DRESTORE***Command*

Restores the display content previously saved in array *a(0)*.

**Syntax:**

```
DRESTORE a(0)
```

**Related commands and functions:**

CLS, DSAVE

**DSAVE***Command*

The actual display content is saved in array *a(0)* (of `char`). With a display size of 20 x 4 characters the size of *a(0)* has to be at least 80.

**Syntax:**

```
DSAVE a(0)
```

**Related commands and functions:**

CLS, DRESTORE

**ECHO***Command*

Switches echo mode of a communication channel on or off.

**Syntax:**

```
ECHO ON|OFF
ECHO s$,ON|OFF
```

**Example:**

```
ECHO "AUX1:",ON
```

**Related commands and functions:**

PROMPT, SHELL

**EDIT***Command (with display only)*

Starts the text editor. If a line number *n* is given, the cursor is positioned at the beginning of this line. If file name *s\$* is missing, the editor starts with the **FILE/LOAD** menu. If a format string is given instead of a name, only the matching files are listed.

**Syntax:**

```
EDIT [s$[,n]]
```

**Example:**

```
EDIT "TEST1.BAS"
EDIT name$,errorline
EDIT "*.BAS"
```

**Related commands and functions:****END***Command*

Terminates a program (END) or a block (END IF, END SELECT). When terminating a program, all open files are closed.

**Syntax:**

```
END
END IF
END SELECT
```

**Related commands and functions:**

```
IF..THEN..ELSE, SELECT..CASE
```

**EOF***Function*

Returns -1 (TRUE), if the end of file *n* is reached, and 0 (FALSE), if not.

**Syntax:**

```
a=EOF (n)
```

**Example:**

```
OPEN "TEST.TXT" FOR INPUT AS #1
DO
  PRINT INPUT$(1,1);
LOOP UNTIL EOF(1)
```

**Related commands and functions:**

```
OPEN
```

**EOLCHAR***Command*

Sets the character which is used as the end-of-line character during an INPUT or LINE INPUT command. Default value is carriage-return (ASCII code 13).

**Syntax:**

```
EOLCHAR n
EOLCHAR s$
```

**Example:**

```
EOLCHAR 10
EOLCHAR "*"
```

**Related commands and functions:**

```
INPUT, LINE INPUT
```

**ERL***Function*

Returns the line number, where the last error occurred.

**Syntax:**

```
a=ERL
```

**Related commands and functions:**

```
ERR, ERR$
```

<b>ERR</b>	<p><i>Function</i></p> <p>Returns the error code of the last error.</p> <p><b>Syntax:</b> a=ERR</p> <p><b>Related commands and functions:</b> ERL, ERR\$</p>
<b>ERR\$</b>	<p><i>Function</i></p> <p>Returns a string containing the description of error code n.</p> <p><b>Syntax:</b> s\$=ERR\$(n)</p> <p><b>Example:</b> PRINT ERR\$(ERR)</p> <p><b>Related commands and functions:</b> ERL, ERR</p>
<b>ERROR</b>	<p><i>Command</i></p> <p>Switches event processing in the case of an error on or off.</p> <p><b>Syntax:</b> ERROR ON OFF</p> <p><b>Related commands and functions:</b> ON xx GOTO GOSUB</p>
<b>EXEC</b>	<p><i>Command</i></p> <p>Executes commands in a file. If commands with line numbers are included, they are added to the current program, but not executed immediately. Execution can be stopped with command EXIT.</p> <p><b>Syntax:</b> EXEC s\$</p> <p><b>Example:</b> EXEC "TEST.BAS"</p> <p><b>Related commands and functions:</b> LOAD, SAVE, EXIT</p>
<b>EXECERRORS</b>	<p><i>Command</i></p> <p>If during a file execution (with EXEC) an error occurs, the execution is normally terminated. You can prevent this with the command EXECERRORS OFF. This is useful, if in a program a file is executed which may contain e.g. syntax errors.</p> <p><b>Syntax:</b> EXECERRORS ON OFF</p> <p><b>Related commands and functions:</b> EXEC, FERL, FERR</p>
<b>EXECSTR</b>	<p><i>Command</i></p> <p>Executes commands in a string. If the string contains lines with a line number, these lines are added to the program listing.</p>

This command is useful to execute G-Codes with variables. Only a string variable can be used, a string constant (e.g. EXECSTR "G00 X0") is not possible.

**Syntax:**

```
EXECSTR s$
```

**Example:**

```
EXECSTR "G01 X"+2*xofs
```

**Related commands and functions:**

```
EXEC
```

**EXIT***Command*

Terminates a DO..LOOP or FOR..NEXT or with EXEC started execution early. Hint: If you don't terminate a DO..LOOP or FOR..NEXT execution with EXIT but just jump out of the loop, a stack overflow error may occur.

**Syntax:**

```
EXIT DO
EXIT FOR
EXIT
```

**Related commands and functions:**

```
DO..LOOP, FOR..NEXT, EXEC
```

**FERL***Function*

Returns the file line in which an error during an execution with EXEC occurred.

**Syntax:**

```
a=FERL
```

**Example:**

```
PRINT FERL
```

**Related commands and functions:**

```
EXEC, EXECERRORS, FERR
```

**FERR***Function*

Returns the error code of last error during a file execution with EXEC.

**Syntax:**

```
a=FERR
```

**Example:**

```
PRINT FERR
```

**Related commands and functions:**

```
EXEC, EXECERRORS, FERL
```

**FILES***Command*

Shows the directory of a device. If no device name is given, SID1: is used as default. If option , 1 is used, all files, even those with .SYS as extension are shown. You can use wildcards (\*,?) in the file name.

**Syntax:**

```
FILES [s$][,1]
```

**Example:**

```
FILES
FILES "*.BAS"
FILES "**.*",1
```

**Related commands and functions:**

FORMAT, LOAD, SAVE, EXEC

**FIX***Function*

Converts numerical expression *a* to an integer by setting the fractional part to zero.

**Syntax:**

*n*=FIX(*a*)

**Example:**

```
PRINT FIX(65.6)
```

**Related commands and functions:**

ABS, CINT, FRAC, INT

**FOR. .NEXT***Command*

Repeats a block of commands until counter variable *a*, starting at *astart* is equal or greater than terminal value *aend*. The optional increment or decrement value is given by *astep*, default is +1.

**Syntax:**

```
FOR a = astart TO aend [STEP astep]
  [Commandsblock]
NEXT [a]
```

**Example:**

```
FOR i = 1 TO 100: PRINT i: NEXT i
FOR x = 100.5 TO 13.2 STEP -0.4
  PRINT x
NEXT
```

**Related commands and functions:**

DO..LOOP, EXIT

**FORMAT***Command*

Formats a device. A device name must be given, e.g. "SID1:". All data is erased. FLASH devices have to be updated with the UPDATE command.

**Syntax:**

```
FORMAT s$
```

**Example:**

```
FORMAT "SID1:"
```

**Related commands and functions:**

FILES, LOAD, SAVE, EXEC

**FRAC***Function*

Returns the fractional part of a fix expression as integer.

**Syntax:**

*n*=FRAC(*a*)

**Example:**

```
PRINT FRAC (65.75)
```

**Related commands and functions:**

```
ABS, CINT, FIX, INT
```

**FRE***Function*

Returns information about the available memory. `FRE (0)` returns the total available memory, `FRE (1)` the largest block, and `FRE (2)` the available stack size.

**Syntax:**

```
n1=FRE (n2)
```

**Related commands and functions:**

```
MEM, STACKSIZE, WRITEPREFS
```

**GETFILENAME\$***Function (with display only)*

Reads a file name. String `title$` is used as a title (e.g. "LOAD FILE"). String `sel$` is used to select the files, only matching file names are displayed. Flag variable `n` allows to determine, whether the line "NEW LINE" is added (`n=0`) or not (`n=1`). If this option is used, a custom file name can be edited, whereas string `default$` is used as a default. Files with extension `.SYS` are not shown.

**Syntax:**

```
name$=GETFILENAME$(title$,sel$,n[,DEFAULT$])
```

**Example:**

```
name$=GETFILENAME$("Load File","*.BAS",0)
```

```
n$=GETFILENAME$("SAVE","*.TXT",1,"NONAME.TXT")
```

**Related commands and functions:**

```
MENU
```

**GOSUB .. RETURN***Command*

Jumps to the subroutine in line `n`. Command `RETURN` allows to jump back immediately after the `GOSUB` command. A subroutine should always be exited with `RETURN`, otherwise a stack overflow error may occur.

**Syntax:**

```
GOSUB n
```

**Example:**

```
100 GOSUB 1000
```

```
110 END
```

```
1000 PRINT "Hallo!"
```

```
1010 RETURN
```

**Related commands and functions:**

```
GOTO
```

**GOTO***Command*

The program is continued in line `n`.

**Syntax:**

GOTO n

**Related commands and functions:**

GOSUB, RETURN

## HEX\$

*Function*

Returns a string which is n2 characters long, containing the hexadecimal representation of integer expression n1.

**Syntax:**

s\$=HEX\$(n1, n2)

**Example:**

```
100 PRINT HEX$(10000, 4)
```

**Related commands and functions:**

BIN\$, OCT\$

## IF..THEN..ELSE..END IF

*Command*

Calculates the value of boolean expression nb and executes the command block after THEN, if the expression is TRUE. If the expression is FALSE, the command block after ELSE is executed. The ELSE branch can be omitted.

**Syntax:**

```
IF nb THEN
  command block 1
ELSE
  command block 2
END IF
```

**Example:**

```
IF a+b<>125 THEN PRINT "1"
  ELSE PRINT "2"
END IF
```

**Related commands and functions:**

GOTO

## INDENT

*Command*

Switches the automatic formatting of the program listing on or off.

**Syntax:**

INDENT ON|OFF

**Related commands and functions:**

LIST

## INPUT

*Command*

Reads a list of variables. The channel number #n is optional. If the channel is a communication device (e.g. STD:) and the input was wrong, an error message is displayed and the user can start again. If the channel is not a communication device (e.g. SID1:), the program terminates with an error in case of a wrong input.

**Syntax:**

```
INPUT [;]["Text"{;|,}] var1[,var2[,var3..]]
INPUT #n,var1[,var2[,var3..]]
```

**Related commands and functions:**

LINE INPUT, INPUT\$, TINPUT, TINPUTC, TINPUTL

**INPUT\$***Function*

Reads *n1* characters from a file or a device. If no channel number *#n2* is given, STD: (keyboard and COM1:) is used as default.

**Syntax:**

```
s$=INPUT$(n1[, [#]n2])
```

**Related commands and functions:**

INPUT, LINE INPUT, TINPUT, TINPUTC, TINPUTL

**INPUTF***Command*

Reads a list of variables. The channel number *#n* is optional. Integer variable *flag* returns an error code, if an input error occurred or 0 if the input was successful.

**Syntax:**

```
INPUTF flag,["Text"{;|,}] var1[,var2..]
INPUTF #n,flag,var1[,var2[,var3..]]
```

**Related commands and functions:**

LINE INPUT, INPUT, INPUT\$, TINPUT, TINPUTC, TINPUTL

**INSTR***Function*

Returns the position of the first occurrence of string *s2\$* in string *s1\$*. The search is started at position *n2*. *n2* is optional. *s2\$* can also be replaced by a ASCII-Code.

**Syntax:**

```
n1=INSTR([n2,]s1$,s2$)
n1=INSTR([n2,]s1$,n) ' n=1..255
```

**Related commands and functions:**

INPUT, LINE INPUT

**INT***Function*

Returns the largest integer, which is greater than or equal to numerical expression *a*.

**Syntax:**

```
n=INT(a)
```

**Related commands and functions:**

ABS, CINT, FIX, FRAC

**KEY***Command*

Switches the event processing for keyboard events on or off.

**Syntax:**

```
KEY ON|OFF
```

**Related commands and functions:**

ON xx GOTO|GOSUB

**KEYTIME***Function*

Returns the time how long the currently pressed key is already pressed (in 1/1024 seconds).

**Syntax:**

n=KEYTIME

**Related commands and functions:**

KEY, KEYREPEAT

**KEYREPEAT***Command*

Sets parameters of the repetition function for the keyboard. a1 is the time (in seconds) until the first repetition. a2 is the time between the following repetitions. a3 is the time between the following repetitions in fast mode. After n characters the fast mode is switched on. If the **START** or **STOP** key is pressed or the **START** or **NOTAUS** command is used, the relays are switched on respectively switched off for at least a4 seconds.

These values can be written permanently with command **WRITEPREFS** and are then reloaded at power on.

**Syntax:**

KEYREPEAT a1,a2,a3,n,a4

**Related commands and functions:**

KEY, KEYTIME, START, NOTAUS

**LCASE\$***Function*

Converts all characters in a string to lower case.

**Syntax:**

s\$=LCASE\$(s\$)

**Related commands and functions:**

UCASE\$

**LED***Command*

Switches the LEDs on the keyboard on, off or in blink mode.

<b>n</b>	<b>key</b>
1	REF
2	TEACH
3	EDIT
4	STEP

All other LEDs are switched automatically.

**Syntax:**

LED [n1][,n2[,n3..]] ON|OFF|BLINK

**LEFT\$***Function*

Returns a string containing the first n characters of string s\$.

**Syntax:**

s\$=LEFT\$(s\$,n)

**Related commands and functions:**

LEN, MID\$, RIGHT\$

<b>LEN</b>	<i>Function</i> Returns the length of string s\$. <b>Syntax:</b> n=LEN(s\$) <b>Related commands and functions:</b> LEFT\$, MID\$, RIGHT\$
<b>LET</b>	<i>Command</i> Assigns value value to variabe varname. This command is not necessary and it is not displayed in a listing. <b>Syntax:</b> LET varname=value : ` equal to varname=value
<b>LINE INPUT</b>	<i>Command</i> Reads a line. Channel number #n is optional. <b>Syntax:</b> LINE INPUT [;][“Text”]; s\$ LINE INPUT #n,s\$ <b>Related commands and functions:</b> INPUT, INPUT\$, TINPUT, TINPUTC, TINPUTL
<b>LIST</b>	<i>Command</i> Displays a program listing. The start line n1 and the end line n2 are optional. <b>Syntax:</b> LIST [n1] [-n2] <b>Related commands and functions:</b> IDENT
<b>LOAD</b>	<i>Command</i> In the current version equal to EXEC. <b>Syntax:</b> LOAD s\$ <b>Related commands and functions:</b> EXEC
<b>LOC</b>	<i>Function</i> Returns the current read/write position within file n. <b>Syntax:</b> n=LOC(n) <b>Related commands and functions:</b> CLOSE, LOF, OPEN, SEEK
<b>LOCATE</b>	<i>Command (with display only)</i> Sets cursor at position n1,n2. <b>Syntax:</b> LOCATE n1,n2

**Related commands and functions:**

CURSOR

**LOF***Function*Returns the file size of file *n*.**Syntax:***n*=LOF(*n*)**Related commands and functions:**

CLOSE, LOC, OPEN, SEEK

**LTRIM\$***Function*Deletes all spaces, tabs and control characters at the beginning of string *s\$*.**Syntax:***s\$*=LTRIM\$(*s\$*)**Related commands and functions:**

RTRIM\$

**MEM***Command*

Displays information about the memory usage.

**Syntax:**

MEM

**Related commands and functions:**

FRE

**MENU***Function (with display only)*Returns the number of a selected menu item in a predefined menu *men(0)*. If the selection is aborted with **ESC**, 0 is returned. *titel\$* is used as menu header.**Syntax:***n*=MENU(*titel\$*,*men(0)*)**Example:**

```
DIM men1(3) AS STRING
men1(1)="LOAD"
men1(2)="SAVE"
men1(3)="EXIT"
sel=MENU("FILE",men1(0))
```

**Related commands and functions:**

DIM, MESSAGE

**MESSAGE***Command (with display only)*

Displays a string or an error message and waits for a pressed key.

**Syntax 1:**MESSAGE *n* : ' error code**Syntax 2:**MESSAGE *s\$* : ' string**Related commands and functions:**

MENU

**MID\$***Function*

Returns  $n_2$  characters of string  $s$  starting at position  $n_1$ . If  $n_2$  is omitted, the rest of string  $s$  is returned.

**Syntax:**

```
s$=MID$(s$,n1[,n2])
```

**Related commands and functions:**

LEFT\$, LEN, RIGHT\$

**MODE***Command*

Sets or displays parameters of the serial interface. Maximum Baudrate and exact values depend on the equipment. Small deviations from the desired value can occur, but generally don't affect the data transmission. As parity the modes NONE, EVEN, ODD, MARK and SPACE are supported. The bit count can be 5 to 8, the stop bits 1 or 2. The handshake mode is NONE, RTSCTS or XONXOFF.

**Syntax 1:**

```
MODE COMn:baudrate,parity,bits,stop,handshake
```

**Syntax 2:**

```
MODE COMn:
```

**Example:**

```
MODE COM1:19200,NONE,8,1,XONXOFF
```

**NETMASTER***Command*

NETMASTER ON puts the controller in the network master mode. In that mode it is possible to switch to the command line of a different controller in the network. The other controllers can be connected via a serial interface or CAN interface (see CONNECT command). The current controller can be recognized by the number or letter preceding the prompt >. The character M implies that commands go to the master controller.

Communication with slaves can be recognized by the character S or the slave number, if the slave controller is already switched to slave mode (see NETSLAVE command). The current controller can be selected with a command line beginning with the character @ followed by the controller number. All other characters or commands in this line are ignored. The master controller has number 0, all slaves the numbers assigned with the CONNECT command.

The master mode is switched off using the NETMASTER OFF command.

**Example:**

```
>NETMASTER ON
M>CONNECT 2,"COM1:"
M>@2
S>
```

**Syntax:**

```
NETMASTER ON|OFF
```

**Related commands and functions:**

CONNECT, NETSLAVE

**NETSLAVE***Command*

NETSLAVE ON puts the controller in the network slave mode. s\$ is the communication interface (serial or CAN), the optional parameter n is the slave number. If omitted, only a S is displayed preceding the prompt, else the slave number is shown. The slave number should be the same as the number given in the CONNECT command. NETSLAVE OFF puts the controller back to the normal mode.

**Syntax:**

NETSLAVE OFF

NETSLAVE s\$[,n]

**Example:**

NETSLAVE "COM1:",12

NETSLAVE "CAN1:10",10

**Related commands and functions:**

CONNECT, NETMASTER

**NEW***Command*

The event processing is switched off (if not prevented earlier with CONTEVENTS ON), the program and variable memory is cleared, open files are closed.

**Syntax:**

NEW

**Related commands and functions:**

CLEAR, CONTEVENTS

**NEWLIST***Command*

An existing program listing is locked and hidden, a new program can be typed in. The old program is still be used for event processing, if no new ON xx GOTO|GOSUB commands are used. Thus it is possible to write a user application (e.g. using G codes), while hardware dependent events are unafflicted.

**Syntax:**

NEWLIST

**Related commands and functions:**

CLEAR, CONTEVENTS, NEW, ON xx GOTO|GOSUB

**OCT\$***Function*

Returns a string which is n2 characters long, containing the octal representation of integer expression n1.

**Syntax:**

s\$=OCT\$(n1,n2)

**Example:**

100 PRINT OCT\$(10000,8)

**Related commands and functions:**

BIN\$, HEX\$

## ON

### *Command*

Sets the program line to which is jumped if the event `event` occurs. `event` can be one of the following:

#### **CAN (n)**

A CAN-Frame was received on channel `n`.

#### **COM (n)**

A character was received via serial interface `n`.

#### **CTRLCODE**

A function key (e.g. **MENU**, **ESC**, **TEACH ..**) was pressed or the corresponding ASCII character was read via the serial interface.

#### **ERROR**

A run-time error occurred (e.g. division by zero).

#### **KEY**

A key on the front panel was pressed.

#### **PORT (n)**

The programmed edge (see command `PORT (n)`) was detected on input `n`.

#### **TIMER (n)**

This event occurs every `n` milliseconds.

#### **Syntax:**

`ON event GOTO|GOSUB n`

#### **Related commands and functions:**

`COM`, `CTRLCODE`, `ERROR`, `KEY`, `PORT`, `TIMER`

## OPEN

### *Command*

Opens a file. Device and file name are given in string `name$`. If the device name is omitted, `SID1:` is used as default. File names are not supported on devices without a file system (e.g. `COM1:`).

`mode` can be one of the following:

#### **INPUT**

File is read-only.

#### **OUTPUT**

File is write-only. An existing file with same name is overwritten.

#### **RANDOM**

File can be read and written. An existing file with same name is overwritten.

#### **APPEND**

File can be read and written. If a file with same name exists, the write pointer is set to the end of the file.

If the optional parameter `FLAG` exists, the program is not terminated in case of an error (e.g. invalid file name), but the error code is stored in variable `n2`.

The following devices are supported (equipment dependent):

`COM1:` serial interface

`COM2:` serial interface

COM3: serial interface  
 COM4: serial interface  
 COM5: serial interface  
 DIS: display  
 KEY: keyboard  
 SID1: EEPROM disc  
 SID0: FLASH disc (see UPDATE command)  
 STD: standard input (COM1: and KEY:) and output  
 (COM1: and DIS:)  
 AUX1: auxiliary device (see ASSIGN command)  
 AUX2: auxiliary device (see ASSIGN command)  
 AUX3: auxiliary device (see ASSIGN command)  
 AUX4: auxiliary device (see ASSIGN command)  
 CAN1: CAN-Bus

The CAN bus can be used like a serial connection between a master and multiple slaves. For that purpose the CAN identifier has to be set using the CANID 0, . . command. The communication can use 31 logical channels, each assigned normally to one slave. The channel number is given like a file name following the colon, e.g. "CAN1:21".

**Syntax:**

```
OPEN name$ FOR mode AS [#]n1 [FLAG n2]
```

**Example:**

```

OPEN "COM1:" FOR RANDOM AS #1
OPEN "SID0:CONFIG.SYS" FOR OUTPUT AS #2
OPEN "TEST.TXT" FOR INPUT AS #3
OPEN "CAN1:7" FOR RANDOM AS #4

```

**Related commands and functions:**

CANID, CLOSE, MODE, OPENSTR, UPDATE

**OPENSTR***Command*

Opens string s\$ as a file.

**Syntax:**

```
OPENSTR s$ AS [#]n
```

**Related commands and functions:**

CLOSE, OPEN

**PARITY***Function*

Calculates the parity of integer n. 0 is returned for even parity, -1 for odd.

**Syntax:**

```
n=PARITY(n)
```

**PI***Function*

Returns  $\pi$  as fix value.

**Syntax:**

```
a=PI
```

<b>PININ</b>	<p><i>Function</i></p> <p>Returns the level of input pin <math>n</math> (see appendix). A logical 1 (TRUE, resp. -1) corresponds to a 24V input level, a logical 0 (FALSE, resp. 0) to 0V.</p> <p><b>Syntax:</b>  <code>n=PININ(n)</code></p> <p><b>Example:</b>  <code>PRINT PININ(12)</code></p> <p><b>Related commands and functions:</b>  PINOUT, PORTIN, PORTOUT, PORT</p>
<b>PINOUT</b>	<p><i>Command</i></p> <p>Sets output pin <math>n1</math> to level <math>n2</math>. A logical 1 corresponds to a 24V input level, a logical 0 to 0V.</p> <p><b>Syntax:</b>  <code>PINOUT n1,n2</code></p> <p><b>Example:</b>  <code>PINOUT 1,1</code></p> <p><b>Related commands and functions:</b>  PININ, PORTIN, PORTOUT, PORT</p>
<b>POPSTACK</b>	<p><i>Command</i></p> <p>Removes the top element of the basic stack. A stack element is created e.g. by a DO, a FOR or a GOSUB command. If the element is not removed by the corresponding commands (LOOP, NEXT, RETURN) you have to do this using POPSTACK, otherwise a stack overflow may occur.</p> <p><b>Syntax:</b>  <code>POPSTACK</code></p> <p><b>Related commands and functions:</b>  CLEARSTACK, FRE, STACKSIZE</p>
<b>PORT</b>	<p><i>Command</i></p> <p>Switches the event processing for input edge detection on or off. <code>PORT(n) RISING</code> detects a rising edge, <code>PORT(n) FALLING</code> a falling edge. The edge detection is only possible with inputs 1 to 8, depending on the controller model up to 16.</p> <p><b>Syntax:</b>  <code>PORT(n) RISING FALLING OFF</code></p> <p><b>Related commands and functions:</b>  <code>ON xx GOTO GOSUB</code></p>
<b>PORTIN</b>	<p><i>Function</i></p> <p>Returns the input levels of 8 bit input port <math>n</math>. Depending on the equipment, <math>n</math> may be 1 to 4. A logic 1 corresponds to a 24 V input level, a logic 0 to a 0 V level.</p> <p><b>Syntax:</b>  <code>n=PORTIN(n)</code></p>

**Example:**

```
PRINT BIN$(PORTIN(1), 8)
```

**Related commands and functions:**

```
PORTOUT, PORT
```

**PORTOUT***Command*

Sets the outputs of 8 bit output port to the value `n2`. Depending on the equipment, `n` may be 1 to 3. A logic 1 corresponds to a 24 V output level, a logic 0 to a 0 V level.

**Syntax:**

```
PORTOUT n1, n2
```

**Example:**

```
PORTOUT 1, &b10011100
```

**Related commands and functions:**

```
PORTIN, PORT
```

**PRINT***Command*

Prints strings or string representations of numerical expressions to the standard output channel or to a given file `#n`.

Expressions separated by semicola are printed without spaces, expressions separated by commata are printed with tabulators (ASCII code 9) between them. The output is terminated with CR/LF (ASCII codes 13 and 10), if the PRINT command doesn't end with a comma or semicolon.

**Syntax:**

```
PRINT [#n,][a1|s1$][;|,]..
```

**Example:**

```
PRINT "HALLO";CHR$(33)
```

```
PRINT 100.0,20;
```

```
PRINT #1,"TEST"
```

**Related commands and functions:**

```
PRINT USING, WRITE
```

**PRINT USING***Command*

Prints formatted strings or formatted string representations of numerical expressions to the standard input and output channel or to a given file `#n`. Expressions separated by semicola are printed without spaces, expressions separated by commata are printed with tabulators (ASCII code 9) between them. The output is terminated with CR/LF (ASCII codes 13 and 10), if the PRINT command doesn't end with a comma or semicolon.

Some characters in the formatting string `format$` have special functions:

```
###.##   Number of figures before and after the decimal
          point. Leading zeros are replaced by spaces.
~. #     Unlimited figures before the decimal point
$###.##  Display leading zeros
+###.##  Display sign
&        Print entire string
```

! Print first character of a string  
 Print following special character (e.g. #)  
 \ \ Print n characters of a string  
 n = ( number of spaces between \\ ) + 2

**Syntax:**

```
PRINT [#n,] USING format$; [a1|s1$][;|,]..
```

**Example:**

```
PRINT USING "X: ###.##";SIN(PI/3)
```

**Related commands and functions:**

```
PRINT, WRITE
```

**PROMPT***Command*

Switches the input prompt on or off.

**Syntax:**

```
PROMPT ON|OFF
```

**Related commands and functions:**

```
ECHO, SHELL
```

**PULSEOUT***Command*

Switches the pulse output n on or off. If period and hightime are given, the output is switched on. Period and hightime are given in milliseconds (integer or fix). A period value of 0 switches the output off (low level).

**Syntax:**

```
PULSEOUT n,period,hightime      ' switch on
PULSEOUT n,0                    ' switch off
```

**Example:**

```
PULSEOUT 1,20.0,1.5
```

**RANDOMIZE***Command*

Initialises the pseudo random generator with integer n.

**Syntax:**

```
RANDOMIZE n
```

**Related commands and functions:**

```
RND
```

**REM***Command*

The rest of the program line is treated as a remark. You can also use the character ´.

**Syntax:**

```
REM
```

**RENEW***Command*

Clears the program listing entered during the execution of the main program. The main program must first be protected with NEWLIST.

**Syntax:**

```
RENEW
```

**Related commands and functions:**

NEW, NEWLIST

**RENUMBER***Command*Renumbers the lines of a program. Start line is  $n_1$ , step is  $n_2$ .**Syntax:**RENUMBER  $n_1, n_2$ **RESET***Command*

Executes a hardware reset.

**Syntax:**

RESET

**RIGHT\$***Function*Returns a string containing the last  $n$  characters of string  $s$ .**Syntax:** $s = \text{RIGHT\$}(s, n)$ **Related commands and functions:**

LEN, LEFT\$, MID\$

**RND***Function*

Returns a 32 bit pseudo random integer.

**Syntax:** $n = \text{RND}$ **Related commands and functions:**

RANDOMIZE

**ROTATE***Function*Rotates 32 bit integer  $n_1$  by  $n_2$  places.**Syntax:** $n = \text{ROTATE}(n_1, n_2)$ **Related commands and functions:**

ASHIFT, SHIFT

**RTRIM\$***Function*Deletes all spaces, tabs and control characters at the end of string  $s$ .**Syntax:** $s = \text{RTRIM\$}(s)$ **Related commands and functions:**

LTRIM\$

**RUN***Command*Starts execution of a program. Start line  $n$  is optional.**Syntax:**RUN [ $n$ ]**Related commands and functions:**

END

**SAVE***Command*

Saves a program with name `name$`. If no device name is given, `SID1:` is used as default. FLASH devices must be updated using the `UPDATE` command.

**Syntax:**

```
SAVE name$
```

**Related commands and functions:**

```
EXEC, FORMAT, LOAD, OPEN, UPDATE
```

**SEEK***Command*

Sets read/write pointer of file `n1` to position `n2`.

**Syntax:**

```
SEEK [#]n1,n2
```

**Related commands and functions:**

```
OPEN
```

**SELECT .. CASE***Command*

Executes one of several possible command blocks according to the value of a given test expression. As compare operator `cmp` can `=`, `>`, `<`, `>=`, `<=` or `<>` be used.

**Syntax:**

```
SELECT CASE test
  CASE expression: command block
  CASE IS cmp expression: command block
  CASE expr TO expr: command block
  CASE ELSE command block
END SELECT
```

**Example:**

```
FOR i=1 TO 5
  SELECT CASE i
    CASE 1: PRINT "1"
    CASE 2 TO 5: PRINT "2..5"
    CASE IS >= 6: PRINT ">=6"
  END SELECT
NEXT i
```

**Related commands and functions:**

```
IF..THEN
```

**SGN***Function*

Returns the sign of a numerical expression.

**Syntax:**

```
n=SGN(a)
```

**Example:**

```
PRINT SGN(-3)
PRINT SGN(0.4)
```

**Related commands and functions:**

```
ABS
```

<b>SHELL</b>	<p><i>Command</i></p> <p>Switches the command line editor, the echo mode and the prompt on or off.</p> <p><b>Syntax:</b> SHELL ON OFF</p> <p><b>Related commands and functions:</b> ECHO, PROMPT</p>
<b>SHIFT</b>	<p><i>Function</i></p> <p>Shifts a 32 bit integer <math>n_1</math> logically by <math>n_2</math> places.</p> <p><b>Syntax:</b> <math>n = \text{SHIFT}(n_1, n_2)</math></p> <p><b>Related commands and functions:</b> ROTATE</p>
<b>SIN</b>	<p><i>Function</i></p> <p>Calculates the sine of numerical expression <math>a</math>.</p> <p><b>Syntax:</b> <math>a = \text{SIN}(a)</math></p> <p><b>Example:</b> PRINT SIN(x) PRINT SIN(0.4)</p> <p><b>Related commands and functions:</b> ACOS, ASIN, COS</p>
<b>SLEEP</b>	<p><i>Command</i></p> <p>Waits <math>n</math> milliseconds. The event processing is unaffected.</p> <p><b>Syntax:</b> SLEEP <math>n</math></p> <p><b>Related commands and functions:</b> TIME</p>
<b>SPACE\$</b>	<p><i>Function</i></p> <p>Create a string containing <math>n</math> spaces.</p> <p><b>Syntax:</b> <math>s\\$ = \text{SPACE\\$}(n)</math></p> <p><b>Related commands and functions:</b> STRING\$</p>
<b>SQR</b>	<p><i>Function</i></p> <p>Calculates the square root of numerical expression <math>a</math>.</p> <p><b>Syntax:</b> <math>a = \text{SQR}(a)</math></p>
<b>STACKSIZE</b>	<p><i>Command</i></p> <p>Sets the size of the BASIC stack to <math>n</math> bytes. This preference has to be written permanently by using the WRITEPREFS</p>

command and is used after the next reset or power up.

**Syntax:**

STACKSIZE n

**Related commands and functions:**

WRITEPREFS

**STR\$***Function*

Returns the string representation of numerical expression a.

**Syntax:**

s\$=STR\$(a)

**Related commands and functions:**

VAL

**STRING\$***Function*

Returns a string containing n1 characters with ASCII code n2, respectively the first character of string s\$.

**Syntax:**

s\$=STRING\$(n1, n2 | s\$)

**Related commands and functions:**

SPACE\$

**SYNC***Command*

Synchronizes the program execution with the system timer. The execution is interrupted until the system timer reaches a value which is divisible by n. During this time no events are monitored. For that reason this command should only be used in special cases. Different synchronization delays can occur if the system timer runs over (after about 1 000 000 000 milliseconds). The standard system frequency is 1024 Hz.

**Syntax:**

SYNC n

**Related commands and functions:**

SLEEP, SYSTIMER

**SYSTIMER***Command (-m versions only)*

Sets the interval of the system timer to a milliseconds. This command is only implemented in special BIOS versions. The time resolution is about 200 ns. If the system timer is changed all time-related computations and functions deliver wrong results (except SLEEP and TIME). This command should only be used in special cases. Depending on the controller model and load a should not be less than 0.8 ms and especially when using servo motors not greater than 2 ms.

**Syntax:**

SYSTIMER a

**Related commands and functions:**

SLEEP, SYNC

**TIME***Function*

Returns the time since the last reset or power up in milliseconds. After 1 000 000 000 milliseconds the counter will start at 0 again.

**Syntax:**

n=TIME

**Related commands and functions:**

SLEEP

**TIMER***Command*

Switches the event processing for timer events on or off.

**Syntax:**

TIMER ON|OFF|STOP

**Related commands and functions:**

ON xx GOTO|GOSUB

**TINPUT***Command*

Reads a list of variables via channel n. If n=0, the standard input channel is used. Parameter `timeout` is the maximum time in milliseconds to complete the command. `timeout=0` switches timeout off. `flag` is 0, if the input was successful, -1 if not.

**Syntax:**

TINPUT n, flag, timeout, var1[, var2[, var3..]]

**Example:**

TINPUT 2, iflag, 2000, a, b

TINPUT kanal, iflag, 0, a\$

**Related commands and functions:**

LINE INPUT, INPUT\$, INPUT, TINPUTL, TINPUTC

**TINPUTC***Command*

Reads a string of length `count` into variable `string$` form channel n. If n=0, the standard input channel is used. Parameter `timeout` is the maximum time in milliseconds to complete the command. `timeout=0` switches timeout off. `flag` is 0, if the input was successful, -1 if not.

**Syntax:**

TINPUTC n, flag, timeout, count, string\$

**Example:**

TINPUTC 2, iflag, 2000, 10, b\$

TINPUTC kanal, iflag, 0, laenge, a\$

**Related commands and functions:**

LINE INPUT, INPUT\$, INPUT, TINPUTL, TINPUT

**TINPUTL***Command*

Reads a line (finished with CR respectively the character defined with EOLCHAR) into variable `string$` form channel `n`. If `n=0`, the standard input channel is used. Parameter `timeout` is the maximum time in milliseconds to complete the command. `timeout=0` switches timeout off. `flag` is 0, if the input was successful, -1 if not.

**Syntax:**

```
TINPUTL n,flag,timeout,a$
```

**Example:**

```
TINPUTL 2,iflag,2000,a$
TINPUTL kanal,iflag,0,a$
```

**Related commands and functions:**

```
LINE INPUT, INPUT$, INPUT, TINPUTL, TINPUTL
```

**UCASE\$***Function*

Converts all characters in a string to upper case.

**Syntax:**

```
s$=UCASE$(s$)
```

**Related commands and functions:**

```
LCASE$
```

**UPDATE***Command*

Updates a FLASH device (standard `SID0:`) after a `SAVE` or `FORMAT` command or a similar file command.

**Syntax:**

```
UPDATE s$
```

**Example:**

```
UPDATE "SID0:"
```

**Related commands and functions:**

```
FILES, LOAD, SAVE, EXEC, FORMAT
```

**VAL***Function*

Converts a string to a fix or integer value.

**Syntax:**

```
a=VAL(s$)
```

**Related commands and functions:**

```
STR$
```

**VERSION\$***Function*

Returns the software version as string.

**Syntax:**

```
s$=VERSION$
```

**WRITE***Command*

`WRITE` prints unlike `PRINT` the list of expressions in a format which can be read by the `INPUT` command. For that purpose the expressions are separated by commata and strings are enclosed in `""`.

**Syntax:**

```
WRITE [#n,] a1|s1$ [,a2|s2$..]
```

**Related commands and functions:**

```
PRINT
```

**WRITEPREFS***Command*

Writes several preferences permanently.

**Syntax:**

```
WRITEPREFS
```

**Related commands and functions:**

```
CALIBRATE, CONTRAST, KEYREPEAT, STACKSIZE
```

**XPRINT***Command*

Writes a list of strings or numerical expressions into channel *n*. Expressions separated by semicola are printed without spaces, expressions separated by commata are printed with tabulators (ASCII code 9) between them. The output is terminated with CR/LF (ASCII codes 13 and 10), if the PRINT command doesn't end with a comma or semicolon. If *n=0* the standard output channel is used.

**Syntax:**

```
XPRINT n[, [a1|s1$] [;|,]..
```

**Example:**

```
XPRINT outchan, "HALLO";CHR$(33)
```

```
XPRINT 2, 100.0, 20;
```

**Related commands and functions:**

```
PRINT, PRINT USING, WRITE
```

## Motor control commands

### Conventions:

a	numerical expression (integer or fix)
ax	numerical expression, used as X coordinate
ay	numerical expression, used as Y coordinate
az	numerical expression, used as Z coordinate
aw	numerical expression, used as an angle (degrees, zero is the positive x axis, positive values counterclockwise, negative values clockwise)
n	integer
na	integer, used as axis number ( $n_a=1..3$ )
ng	Integer, used as group number ( $n_g=1..8$ )
c	single ASCII encoded character
s\$	string
[..]	optional parameter
Syntax 1	syntax to be used, if group contains 1 axis
Syntax 2	syntax to be used, if group contains 2 axes
Syntax 3	syntax to be used, if group contains 3 axes

### ACC

#### Command

Sets the acceleration for linear and circular movements (in user units/s<sup>2</sup>) of group  $n_g$  to value  $a$ . The command can be executed during a movement and the new value is updated immediately.

#### Syntax:

ACC  $n_g, a$

#### Related commands and functions:

DEC, HDEC, VEL, TRAFO

### ALENGTH

#### Function

Returns the current contour position of group  $n_g$ .

#### Syntax:

$a=ALENGTH(n_g)$

#### Example:

PRINT ALENGTH(1)

#### Related commands and functions:

CONTOUR, LENGTH

### AMPERROR

#### Command

Switches the event processing for amplifier errors on or off. AMPERROR HIGH causes an event, if the amplifier error line is logical high, AMPERROR LOW if it is logical low.

#### Syntax:

AMPERROR HIGH|LOW|OFF

#### Related commands and functions:

MAXDIFF, MAXFORCE, MOTOR

### APOS

#### Function

Returns the actual position of the  $n$ th axis of group  $n_g$ . If axis  $n$

is a servo motor, the back-transformed current position of the incremental encoder is returned, not the calculated desired position (see TPOS).

**Syntax:**

a=APOS (ng, n)

**Example:**

PRINT APOS (1, 1) , APOS (1, 2) , APOS (1, 3)

**Related commands and functions:**

CPOS, TP, TPOS

**ARCA***Command*

Performs a circular movement with angle  $a_w$ , starting at the current position, around the absolute center point  $a_x, a_y, a_z$ . The mode parameter  $n_m$  determines, whether the circular movement is in the XY plane ( $n_m=0$ ), in the YZ plane ( $n_m=1$ ) or in the ( $n_m=2$ ) plane.

**Syntax 2:**

ARCA ng, ax, ay, aw

**Syntax 3:**

ARCA ng, 0, ax, ay, aw

ARCA ng, 1, ay, az, aw

ARCA ng, 2, ax, az, aw

**Example:**

ARCA 1, 100.0, 50.0, 180

**Related commands and functions:**

ARCR

**ARCR***Command*

Performs a circular movement with angle  $a_w$ , starting at the current position, around the relative center point  $a_x, a_y, a_z$ . The mode parameter  $n_m$  determines, whether the circular movement is in the XY plane ( $n_m=0$ ), in the YZ plane ( $n_m=1$ ) or in the ( $n_m=2$ ) plane.

**Syntax 2:**

ARCR ng, ax, ay, aw

**Syntax 3:**

ARCR ng, 0, ax, ay, aw

ARCR ng, 1, ay, az, aw

ARCR ng, 2, ax, az, aw

**Example:**

ARCR 1, +50.0, -50.0, 180

**Related commands and functions:**

ARCA

**AUTOVEL***Command*

If the AUTOVEL mode is switched on, the speed during circular movements is reduced, so that neither acceleration nor deceleration are exceeded.

**Syntax:**

AUTOVEL [ng1[,ng2..] ON|OFF

**Example:**

AUTOVEL ON

**Related commands and functions:**

DEC, ACC, MAXSEGMENTS, RSEGMENTS

**AVEL**

*Function*

Returns the current velocity of group ng respectively of axis n of group ng (n=1: x axis, n=2: y axis, n=3: z axis).

**Syntax 1: liner or circular move**

a=AVEL (ng)

**Syntax 2: position move**

a=AVEL (ng, n)

**Related commands and functions:**

VEL

**BORDER**

*Command*

Limits the movement of the axes to a lower (a1) and an upper (a2) value. If a limit is reached, the movement is stopped immediately without a deceleration profile.

**Syntax 1:**

BORDER ng, a1x, a2x

**Syntax 2:**

BORDER ng, a1x, a2x, a1y, a2y

**Syntax 3:**

BORDER ng, a1x, a2x, a1y, a2y, a1z, a2z

**Example:**

BORDER 1, -200, +200, -130, +150

**CODE**

*Function*

Returns the last value of a G code. Code sel can have the following values:

fix: A, F, I, J, K, R, S, W, X, Y, Z

integer: G, L, M, N

special: C

**Syntax:**

a=CODE (sel)

**Example:**

F100.5 G02

I+100 J-55.5

PRINT CODE (F) , CODE (G) , CODE (I) , CODE (J)

**Related commands and functions:**

ON CTRLCODE GOTO|GOSUB

**CONTINUOUS**

*Command*

Switches the continuous mode for groups ng1, ng2, ... on or off. If the continuous mode is activated, the constant velocity after the acceleration profile is continued as long as movement commands are added (e.g. LINA, LINR, ARCA, ARCR). It is

necessary to use the command `NOWAIT ON` first.

**Syntax:**

`CONTINUOUS ng1 [, ng2 [, ng3 ..]] ON|OFF`

**Related commands and functions:**

`NOWAIT`

**CONTOUR**

*Command*

Switches contour acquisition mode for group `ng1`, `ng2`, ... on or off. A contour consists of one or more linear or circular segments. They can be programmed after `CONTOUR ON` with `LINA`, `LINR`, `ARCA` and `ARCR`. Start position is the actual position. The start position can be moved using the `POSA` or `POSR` command. During contour acquisition mode, no movements are performed. After `CONTOUR OFF` the contour can be used with `MOVER` or `MOVEA`.

**Syntax:**

`CONTOUR ng1 [, ng2 [, ng3 ..]] ON|OFF`

**Example:**

```
CONTOUR ON
LINR 1,0,100
ARCR 1,25,0,-180
CONTOUR OFF
```

**Related commands and functions:**

`ALENGTH`, `CTPOS`, `LENGTH`, `MOVEA`, `MOVER`, `NEWSEG`, `SETCPOS`

**CONTSEG**

*Command*

Used in contour mode to connect two segments with constant velocity, even if segmented mode is selected (`SEGMODE ON`).

**Syntax:**

`NEWSEG ng`

**Related commands and functions:**

`CONTOUR`, `SEGMODE`, `CONTSEG`

**CPOS**

*Function*

Returns the last calculated position of the `n`th axis of group `ng`.

**Syntax:**

`a=CPOS (ng, n)`

**Example:**

```
NOWAIT ON
LINA 1,100,200,300
PRINT CPOS (1,1), CPOS (1,2), CPOS (1,3)
```

**Related commands and functions:**

`APOS`, `TP`, `TPOS`

**CTPOS**

*Function*

Returns the position of axis `n` of group `ng` at contour position `l`.

**Syntax:**

`a=CTPOS (ng, n, l)`

**Example:**

```
CONTOUR ON
LINR 1,100,150
CONTOUR OFF
PRINT CTPOS(1,1,50),CTPOS(1,2,50)
```

**Related commands and functions:**

CONTOUR, SETCPOS, LENGTH, ALENGTH

**CVEL***Function*

Returns the current maximum velocity programmed with VEL respectively POSVEL of group ng respectively axis n of group ng (n=1: x axis, n=2: y axis, n=3: z axis).

**Syntax 1: VEL**

a=CVEL (ng)

**Syntax 2: POSVEL**

a=CVEL (ng, n)

**Related commands and functions:**

AVEL, VEL, POSVEL

**DEC***Command*

Sets the deceleration for linear and circular movements (in user units/s<sup>2</sup>) of group ng to value a. The command can be executed during a movement and the new value is updated immediately.

**Syntax:**

DEC ng, a

**Example:**

```
DEC 1,200
```

**Related commands and functions:**

ACC, HDEC, VEL, TRAFO

**DEFAULTCODE***Command*

If a line contains G code coordinates, but no G code, G01 is automatically executed, if DEFAULTCODE ON was used. Otherwise, only the flags are set, but no command is executed.

**Syntax:**

DEFAULTCODE ON|OFF

**Related commands and functions:**

G-Codes

**FMAX***Command*

Sets the maximum value (in user unit/s) which can be set by the Fa code.

**Syntax:**

FMAX a

**Example:**

```
FMAX 200
```

**Related commands and functions:**

G-Codes

**G-Codes***Command (preliminary)*

G code are CNC commands, which have a special syntax. They are partly implemented in this controller, but all can be emulated using event processing and BASIC commands. A G code consists of a character and a number (variables are not allowed). For certain G codes only integers (*n*) are allowed, the other can handle fix (*f*) values.

**Syntax:**

G00 X*f* Y*f* Z*f*

position move

G01 X*f* Y*f* Z*f*

linear move

G02 [G9*n*] I*f* J*f*

G02 X*f* Y*f* [G9*n*] I*f* J*f*

G02 X*f* Z*f* [G9*n*] I*f* K*f*

G02 Y*f* Z*f* [G9*n*] J*f* K*f*

circular move (clockwise)

G03 [G9*n*] I*f* J*f*

G03 X*f* Y*f* [G9*n*] I*f* J*f*

G03 X*f* Z*f* [G9*n*] I*f* K*f*

G03 Y*f* Z*f* [G9*n*] J*f* K*f*

circular move (counter-clockwise)

G09 A*f* W*f*

polar coordinates

G52 X*f* Y*f* Z*f*

move to reference position

G53

reset coordinate transformation

G54 X*f* Y*f* Z*f*

move coordinate system

G55 X*f* Y*f* Z*f* W*f* [I*f* J*f*]

move and rotate coordinate system (relative)

G56 X*f* Y*f* Z*f* W*f* I*f* J*f*

move and rotate coordinate system (absolute)

G90

absolute coordinates

G91

relative coordinates

M71

relative angle

M72  
absolute angle

Vn  
wait n ms

## GETV

### *Function*

Returns the actual value of an axis parameter.

### **Syntax:**

a=GETV (na, mode)

### **Mode:**

#### **DEADBAND**

Returns the dead band of the PID controller.

#### **DIFF**

Returns the differential value of the PID controller.

#### **FACTOR**

Returns the scale factor between `input1` and `input2` in the PIDD-mode.

#### **FEEDFWD**

Not yet supported.

#### **FORCE**

Returns the current controller output (value between -100 and 100).

#### **IMAX**

Returns the value of the maximum average current of the amplifier.

#### **INT**

Returns the integral value of the PID controller.

#### **IPEAK**

Returns the value of the peak current of the amplifier, if `na` is a servo axis.

#### **ISTANDBY**

Returns the value of the standby current, if `na` is a stepper axis.

#### **ITIME**

Returns the value of the peak current time limit.

#### **MAXFORCE**

Returns the value of the maximum PID controller output.

#### **MAXDIFF**

Returns the maximum difference between current and desired position.

#### **MOTOR**

Returns the actual controller state.

#### **OFFSET**

Returns the offset of the PID controller output.

#### **POL**

Returns the counting direction of the incremental encoder inputs.

#### **PROP**

Returns the proportional value of the PID controller.

**PWMOFFSET**

Returns the PWM offset value.

**PWMPOL**

Returns the PWM output polarity.

**RAPOS**

Returns the actual position of the incremental encoder.

**RTPOS**

Returns the desired position of the axis (raw value, in quadcounts).

**Related commands and functions:**

SET

**GROUP***Command*

Combines one or more axes to a group. Only within a group linear and circular movements are possible. The order determines which axes are X, Y and Z.

**Syntax:**

GROUP ng, na1, [na2[, na3]]

**Related commands and functions:**

HDEC, POSHDEC, STOP

**HALT***Command*

The movements of groups ng1, ng2, ... are terminated using the deceleration set with HDEC or POSHDEC respectively .

**Syntax:**

HALT ng1, [ng2[, ng3..]]

**Related commands and functions:**

HDEC, POSHDEC, STOP

**HDEC***Command*

Sets the deceleration which is used if the HALT command is executed during a linear or circular move, to the value a (in user units/s<sup>2</sup>). The command can be executed during a movement and the new value is updated immediately.

**Syntax:**

HDEC ng, a

**Example:**

HDEC 1, 1000

**Related commands and functions:**

ACC, DEC, VEL, TRAFO, HALT

**INC***Function*

Returns the actual value of incremental decoder n.

**Syntax:**

a=INC (n)

**Example:**

PRINT INC(1)

**Related commands and functions:**

INCFILTER

**INCFILTER***Command*

Sets an input filter for incremental decoder  $n1$ . The filter parameter  $n2$  sets the minimum change of position. This filter may increase control loop stability, but reduces accuracy.

**Syntax:**

```
INCFILTER n1,n2
```

**Example:**

```
INCFILTER 1,1
```

**Related commands and functions:**

```
INC
```

**INDEX***Command*

Switches the event processing for index input events on or off. INDEX RISING detects a rising edge, INDEX FALLING detects a falling edge. Index events are available only on some controllers.

**Syntax:**

```
INDEX RISING|FALLING|OFF
```

**Related commands and functions:**

```
ON xx GOTO|GOSUB
```

**JUMP***Command*

Sets a new command position  $n$  for axis  $na$ . This command should only be used in special cases. New positions can be set with less than 512 Hz for stepper motors and less than 1024 Hz for servo motors.

**Syntax:**

```
JUMP na,n
```

**Example:**

```
JUMP 1,50
```

**LENGTH***Function*

Returns the total length of the contour of group  $ng$ .

**Syntax:**

```
a=LENGTH(ng)
```

**Example:**

```
PRINT LENGTH(1)
```

**Related commands and functions:**

```
ALENGTH, CONTOUR
```

**LINA***Command*

Performs a linear movement starting at the current position to the absolute coordinates  $ax, ay, az$ .

**Syntax 1:**

```
LINA ng,ax
```

**Syntax 2:**

```
LINA ng,[ax][,[ay]]
```

**Syntax 3:**

```
LINA ng,[ax][,[ay]][,az]
```

**Example:**

```
LINA 1,100.0,50.0,100.0
```

**Related commands and functions:**

```
LINR
```

**LINR***Command*

Performs a linear movement starting at the current position to the relative coordinates  $ax, ay, az$ .

**Syntax 1:**

```
LINR ng, ax
```

**Syntax 2:**

```
LINR ng, [ax] [, [ay]]
```

**Syntax 3:**

```
LINR ng, [ax] [, [ay]] [, az]
```

**Example:**

```
LINR 1,-100.0,+50.0,-100.0
```

**Related commands and functions:**

```
LINA
```

**MAXDIFF***Command*

Switches the event processing for the supervision of the maximum difference between current and desired position on or off. The maximum value can be set with the command `SET na, MAXDIFF, a`. Controlling and amplifier of axis  $na$  are automatically switched off, if parameter `AUTO` is used. This automatic mode is switched off with parameter `MANUAL`.

**Syntax:**

```
MAXDIFF ON|OFF
```

```
MAXDIFF AUTO|MANUAL
```

**Related commands and functions:**

```
SET, ON xx GOTO|GOSUB
```

**MAXFORCE***Command*

Switches the event processing for the supervision of the maximum PID controller output on or off. The maximum value can be set with the command `SET na, MAXFORCE, a`.

**Syntax:**

```
MAXFORCE ON|OFF
```

**Related commands and functions:**

```
SET, ON xx GOTO|GOSUB
```

**MAXSEGMENTS***Command*

Sets the number of segments which are checked by the `AUTOVEL` function.

**Syntax:**

```
MAXSEGMENTS ng, n
```

**Related commands and functions:**

```
AUTOVEL, RSEGMENTS
```

**MODE****Command**

Sets motor and amplifier parameters. There are two syntax versions for stepper and for servo motors.

**Syntax for servo motors:**

MODE na, PID, input, output

input can be one of the following

INC (1 | 2 | 3) incremental counter 1,2,3

ADIN (n) analog input (depending on equipment)

output can be:

PWMS (1 | 2 | 3) PWM output with sign

PWMD (1 | 2 | 3) differential PWM

DAOUT (n) analog output (depending on equipment)

UDAOUT (n) unipolar analog output + sign (depending on equipment)

**Syntax for servo motors with 2 encoders:**

MODE na, PIDD, input1, input2, output

In this mode proportional and integral part of the PID algorithm are computed with input2 (e.g. linear encoder), the differential part is computed with input1 (e.g. rotary encoder). The scale factor between input1 and input2 is set with command SET na, FACTOR, a.

input can be one of the following

INC (1 | 2 | 3) incremental counter 1,2,3

ADIN (n) analog input (depending on equipment)

output can be:

PWMS (1 | 2 | 3) PWM output with sign

PWMD (1 | 2 | 3) differential PWM

DAOUT (n) analog output (depending on equipment)

UDAOUT (n) unipolar analog output + sign (depending on equipment)

**Syntax for stepper motors:**

MODE na, SM, output

output can be:

STEPPDIR (1 | 2 | 3) step and direction output 1,2,3

PATTERN (1 | 2 | 3) pattern generator 1,2,3

Motor and amplifier parameters can be set only once after reset or power up.

**Example:**

MODE 1, PID, INC (1), DAOUT (1)

MODE 2, PID, INC (2), PWMS (2)

MODE 3, SM, PATTERN (1)

**Related commands and functions:**

SET

**MOTOR****Command**

Switches the amplifiers and the position controlling on or off.

**Syntax:**

MOTOR [na1][,na2][,na3..] ON|OFF

**Related commands and functions:**

SET, ON xx GOTO|GOSUB

**MOVEA***Command*

Starts a contour move to absolute contour position 1. First a position move to the actual contour position is performed, then the contour move to the desired position starts.

**Syntax:**

MOVEA ng, l

**Example:**

MOVEA 1, 120.0

**Related commands and functions:**

CONTOUR, MOVER

**MOVER***Command*

Starts a contour move to relative contour position 1. First a position move to the actual contour position is performed, then the contour move to the desired position starts.

**Syntax:**

MOVER ng, l

**Example:**

MOVER 1, 120.0

**Related commands and functions:**

CONTOUR, MOVEA

**MOVING***Function*

Returns TRUE, if group ng is moving, FALSE if not.

**Syntax:**

a=MOVING (ng)

**Related commands and functions:**

NOWAIT, WAIT

**NEWCODE***Function*

Returns TRUE, if a new value was set with G code sel. Code sel can be:

fix: A, F, I, J, K, R, S, W, X, Y, Z

integer: G, L, M, N

**Syntax:**

a=NEWCODE (sel)

**Related commands and functions:**

CODE, G-Codes, RESETCODEFLAGS

**NEWSEG***Command*

Causes a stop after the last contour segment during contour move.

**Syntax:**

NEWSEG ng

**Related commands and functions:**

CONTOUR, CONTSEG, SEGMODE

**NOTAUS**

*Command*

Switches the event processing in case of a emergency stop (NOTAUS) on or off, sets the mode of control or causes an emergency stop. In the internal mode a power relay is switched on by the `START` command or by pressing the **START** key. It is switched off by the `NOTAUS` command or by pressing the **STOP** key. In the external mode the external relay controller is supervised. The **START** and **STOP** keys can be used if they are connected.

**Syntax:**

NOTAUS INTERN|EXTERN ; mode  
 NOTAUS ; cause emerg. stop  
 NOTAUS ON|OFF ; event proc. on/off

**Related commands and functions:**

KEYTIME, START

**NOWAIT**

*Command*

Determines, whether the interpreter waits until a movement is finished (`NOWAIT OFF`) or whether following commands can be executed (`NOWAIT ON`).

**Syntax:**

NOWAIT [ng1] [,ng2] [,ng3..] ON|OFF

**Related commands and functions:**

MOVING, WAIT

**ON**

*Command*

Sets the program line to which is jumped if the event `event` occurs. Use only `GOSUB` for the events `AMPERROR`, `MAXDIFF` und `MAXFORCE`. If a `GOTO` branch is desired, use `GOSUB` and clear the stack element with `POPSTACK`, after the source of the events has been cleared (e.g. with `MOTOR OFF`).

`event` can be one of the following:

**AMPERROR (na)**

The amplifier error signal has the programmed level (see `AMPERROR (na)`).

**CODE (sel)**

This event occurs, if a G code with character `sel` (G, E (end of line), D, M, T) is interpreted.

**INDEX (na)**

The programmed edge on index input `na` was detected.

**MAXDIFF (na)**

This event occurs if the difference between desired and current position is greater than the programmed value.

**MAXFORCE (na)**

This event occurs if the PID controller output is greater than the

programmed value.

**NOTAUS**

The NOTAUS detection signal S+ has changed its level from +24 V to 0 V.

**START**

The NOTAUS detection signal S+ has changed its level from 0 V to +24 V.

**TOOLOFF**

This event occurs if a G01, G02 or G03 command is followed by a G00 command.

**TOOLON**

This event occurs if a G00 command is followed by a G01, G02 or G03 command.

**Syntax:**

ON event GOTO|GOSUB n

**Related commands and functions:**

AMPERROR, G-Codes, INDEX, MAXDIFF, MAXFORCE, SET, NOTAUS, START, TOOLOFF, TOOLON

**POSA**

*Command*

Performs a position move of group ng to the given absolute coordinates.

**Syntax:**

POSA ng, [ax][, [ay][, az]]

**Example:**

POSA 1,100.5,,25

**Related commands and functions:**

POSACC, POSDEC, POSHDEC, POSR, POSVEL

**POSACC**

*Command*

Sets the positioning acceleration (in user units/s<sup>2</sup>) of the axes of group ng. The command can be executed during a movement and the new value is updated immediately.

**Syntax 1:**

POSACC, ng, ax

**Syntax 2:**

POSACC ng, [ax][, [ay]

**Syntax 3:**

POSACC ng, [ax][, [ay][, az]]

**Example:**

POSACC 1,1000,1000,100

**Related commands and functions:**

POSA, POSDEC, POSHDEC, POSR, POSVEL

**POSDEC**

*Command*

Sets the positioning deceleration (in user units/s<sup>2</sup>) of the axes of group ng. The command can be executed during a movement and the new value is updated immediately.

**Syntax 1:**

POSDEC, ng, ax

**Syntax 2:**

POSDEC ng, [ax] [, [ay]

**Syntax 3:**

POSDEC ng, [ax] [, [ay] [, az]]

**Example:**

POSDEC 1, 1000, 1000, 100

**Related commands and functions:**

POSA, POSACC, POSHDEC, POSR, POSVEL

**POSHDEC***Command*

Sets the deceleration, which is used if the HALT command is executed during a position move, to the value a (in user units/s<sup>2</sup>). The command can be executed during a movement and the new value is updated immediately.

**Syntax 1:**

POSHDEC, ng, ax

**Syntax 2:**

POSHDEC ng, [ax] [, [ay]

**Syntax 3:**

POSHDEC ng, [ax] [, [ay] [, az]]

**Example:**

POSHDEC 1, 5000, 5000, 2000

**Related commands and functions:**

POSA, POSACC, POSDEC, POSR, POSVEL

**POSR***Command*

Performs a position move of group ng to the given relative coordinates.

**Syntax:**

POSA ng, [ax] [, [ay] [, az]]

**Example:**

POSA 1, 100.5, , 25

**Related commands and functions:**

POSA, POSACC, POSDEC, POSHDEC, POSVEL

**POSVEL***Command*

Sets the positioning velocity (in user units/s) of the axes of group ng. The command can be executed during a movement and the new value is updated immediately.

**Syntax 1:**

POSVEL ng, ax

**Syntax 2:**

POSVEL ng, [ax] [, [ay]

**Syntax 3:**

POSVEL ng, [ax] [, [ay] [, az]]

**Example:**

POSVEL 1, 100, 100, 20

**Related commands and functions:**

POSACC, POSDEC, POSHDEC

**POWERON***Function*

Returns the status of the emergency stop circuit. The return value is `TRUE`, if the **START LED** is green (amplifier power on), and `FALSE`, if it is red (amplifier power off).

**Syntax:**

```
a=POWERON
```

**Example:**

```
PRINT POWERON
```

**Related commands and functions:**

```
START, NOTAUS
```

**RESETCODEFLAGS***Command*

Resets all G code flags.

**Syntax:**

```
RESETCODEFLAGS
```

**Related commands and functions:**

```
G-Codes, CODE, NEWCODE
```

**RLENGTH***Function*

Returns the remaining length while in continuous mode.

**Syntax:**

```
a=RLENGTH (ng)
```

**Related commands and functions:**

```
CONTINUOUS, RSEGMENTS
```

**RSEGMENTS***Function*

Returns the number of segments while in continuous mode.

**Syntax:**

```
a=RSEGMENTS (ng)
```

**Related commands and functions:**

```
AUTOVEL, CONTINUOUS, MAXSEGMENTS, RLENGTH
```

**SCOPE***Command*

Puts every 0.977 ms (1024 Hz) the actual position of axis `na` into array `array(0)`, until the array is filled. The actual position is the incremental encoder position as obtained by `GETV(na, RAPOS)`. Array type can be char or integer.

**Syntax:**

```
SCOPE na, array(0)
```

**Example:**

```
DIM testarray(1000) AS INTEGER
SCOPE 1, testarray(0): SLEEP 50: JUMP 1, 100
SLEEP 950
FOR i=1 to 1000: PRINT testarray(i): NEXT
```

**Related commands and functions:**

```
JUMP
```

**SEGMODE***Command*

Selects the default segmentation mode during contour mode. With **SEGMODE ON** the movement stops between every segment, with **SEGMODE OFF** the movement continues with constant velocity. The mode can be changed individually for every segment using the **NEWSEG** or **CONTSEG** command.

**Syntax:**

**SEGMODE** ng1 [,ng2 [,ng3...]] ON|OFF

**Siehe auch:**

**ALENGTH**, **CONTSEG**, **CTPOS**, **LENGTH**, **MOVEA**, **MOVER**, **NEWSEG**, **SETCPOS**

**SET***Command*

Sets one of several axis controller parameters.

**Syntax:**

**SET** na,mode,a

**Mode:****DEADBAND**

Sets the dead band of the PID controller. This is the difference between desired and current position up to which the PID controller output stays zero.

**DIFF**

Sets the differential value of the PID controller. The range is 0.0 to 32767.0.

**FACTOR**

Sets the scale factor between **input1** and **input2** in the **PIDD**-mode.  $FACTOR = Res(input2) / Res(input1)$ , **Res(n)** is the encoder resolution in increments/length unit.

**FEEDFWD**

Not yet supported.

**IMAX**

Sets the value of the maximum average current (depending on the amplifier). The range is 0 to 100.

**INT**

Sets the integral value of the PID controller. The range is 0.0 to 32767.0.

**IPEAK**

Sets the peak current with amplifier model **PW2000**. The function is identical to **ISTANDBY**.

**ISTANDBY**

Sets the value of the standby current, if **na** is a stepper axis. The range is 0 to 100.

**ITIME**

Sets the value of the peak current time limit. The range is 0 to 100.

**MAXFORCE**

Sets the value of the maximum PID controller output. The range is 0 to 100.

**MAXDIFF**

Sets the maximum difference between current and desired position. The range is 0 to 32767 (in quadcounts).

**MOTOR**

Switches amplifier of axis `na` on or off. Parameter `a` can be ON or OFF.

**OFFSET**

Sets the offset of the PID controller output. The range is -100 to +100. This can e.g. be used for gravity compensation.

**PHASEA, PHASEB, PHASEC, PHASED**

Sets the 16 bit patterns for the pattern generator. Axis `na` has to be a stepper motor.

**POL**

Sets the counting direction of the incremental encoder inputs. `a` can be TRUE or FALSE.

**PROP**

Sets the proportional value of the PID controller. The range is 0.0 to 32767.0.

**PWMOFFSET**

Sets PWM offset. This is useful to compensate the offset of PWM amplifiers. The range is -100 to +100.

**PWMPOL**

Sets the polarity of the PWM output. `a` can be TRUE or FALSE.

**RAPOS**

Sets the actual position of the incremental encoder. This should be used for diagnostics only.

**RTPOS**

Sets the desired position of the PID controller. This should be used for diagnostics only.

**SLFACTOR**

Sets the scale factor between master and slave axis.

Slave position=Master position \* FACTOR. This command should only be used after all axes involved are set to the zero position using SETPOS.

**WAVEFORM1**

Sets the current waveform of phase one of motorcontrollers with micro step amplifiers (CO6100 und CO6500). Parameter `a` is an one dimensional array with size 256 of FIX. The range of the array values is -1 to +1.

**WAVEFORM2**

Sets the current waveform of phase two of motorcontrollers with micro step amplifiers (CO6100 und CO6500). Parameter `a` is an one dimensional array with size 256 of FIX. The range of the array values is -1 to +1.

**Related commands and functions:**

GETV

**SETPOS***Command*

Sets the position (actual and desired) of group `ng`.

**Syntax 1:**

SETPOS ng, ax

**Syntax 2:**

SETPOS ng, ax, ay

**Syntax 3:**

SETPOS ng, ax, ay, az

**Related commands and functions:**

APOS, TPOS, CPOS, TP, TRAFO

**SETCPOS**

*Command*

Sets the current contour position of group ng to position l.

**Syntax:**

SETCPOS ng, l

**Related commands and functions:**

CONTOUR, CTPOS, MOVEA, MOVER

**SLAVE**

*Command*

Couples one axis to another. Depending on parameter APOS or TPOS axis na1 uses the actual position (APOS) or target position (TPOS) of axis na2. If only na1 is given the coupling is solved.

**Syntax:**

SLAVE na1, na2, APOS | TPOS

SLAVE na1

**Example:**

SLAVE 3, 2, APOS

**START**

*Command*

Without option the EIN relay is switched on for the programmed time (see KEYREPEAT). This is the same as pressing the **START** key. The EIN relay must be enabled with `START ENABLE` first. The options `ON` and `OFF` switch the **START** event processing on or off.

**Syntax:**

START [ON | OFF | ENABLE | DISABLE]

**Related commands and functions:**

KEYREPEAT, NOTAUS

**STATUS**

*Function*

Returns the actual state of AMPERROR, MAXDIFF or MAXFORCE. With MAXDIFF and MAXFORCE, the return value `TRUE` means that the values preset with `SET` are exceeded. Used with parameter `MOTOR` the function returns the actual state of the axis controller (`TRUE` = motor control is on).

**Syntax:**

n=STATUS (na, modus)

**Example:**

PRINT STATUS (1, MAXDIFF)

**Related commands and functions:**

SET

<b>STOP</b>	<p><i>Command</i></p> <p>The movement of groups <code>ng1, ng2, ...</code> is stopped immediately without a deceleration profile.</p> <p><b>Syntax:</b>  <code>STOP ng1, [ng2[, ng3...]]</code></p> <p><b>Related commands and functions:</b>  <code>HALT</code></p>
<b>TOOL</b>	<p><i>Command</i></p> <p>Switches the event processing for <code>TOOLON</code> and <code>TOOLOFF</code> events on or off. See <code>ON xx GOTO GOSUB</code> command.</p> <p><b>Syntax:</b>  <code>TOOL ON OFF</code></p> <p><b>Related commands and functions:</b>  <code>ON .. GOTO GOSUB</code></p>
<b>TP</b>	<p><i>Command</i></p> <p>Lists the actual positions of all axes in all groups.</p> <p><b>Syntax:</b>  <code>TP</code></p> <p><b>Related commands and functions:</b>  <code>APOS, CPOS, GROUP, TPOS</code></p>
<b>TPOS</b>	<p><i>Function</i></p> <p>Returns the desired (i.e. calculated) position of the <code>n</code>th axis of group <code>ng</code>.</p> <p><b>Syntax:</b>  <code>a=TPOS(ng, n)</code></p> <p><b>Example:</b>  <code>PRINT TPOS(1, 1), TPOS(1, 2), TPOS(1, 3)</code></p> <p><b>Related commands and functions:</b>  <code>APOS, CPOS, TP</code></p>
<b>TRACKING</b>	<p><i>Command</i></p> <p>Switches the tracking mode for groups <code>ng1, ng2, ...</code> on or off. In tracking mode positioning commands are finished early, if a new position is given. Acceleration and deceleration profiles are used. Tracking mode is not possible during linear or circular movements.</p> <p><b>Syntax:</b>  <code>TRACKING ng1, [ng2[, ng3...]] ON OFF</code></p> <p><b>Related commands and functions:</b>  <code>POSA, POSR</code></p>
<b>TRAFO</b>	<p><i>Command</i></p> <p>Sets the matrix for the coordinate transformation of group <code>ng</code>. Transformation for a group of one axis:</p>

$$x' = x * a$$

Transformation for a group of two axes:

$$x' = x * ax1 + y * ay1$$

$$y' = x * ax2 + y * ay2$$

Transformation for a group of three axes:

$$x' = x * ax1 + y * ay1$$

$$y' = x * ax2 + y * ay2$$

$$z' = z * az$$

**Syntax 1:**

TRAFO ng, a

**Syntax 2:**

TRAFO ng, ax1, ay1, ax2, ay2

**Syntax 3:**

TRAFO ng, ax1, ay1, ax2, ay2, az

**VEL**

*Command*

Sets the deceleration for linear and circular movements (in user units/s<sup>2</sup>) of group ng to value a. The command can be executed during a movement and the new value is updated immediately.

**Syntax:**

VEL ng, a

**Related commands and functions:**

ACC, DEC, HDEC, TRAFO

**WAIT**

*Command*

Waits until the movements of groups ng1, ng2, ... are finished.

**Syntax:**

WAIT ng1[, ng2[, ng3...]]

**Related commands and functions:**

NOWAIT, MOVING

### 3. Appendix A: G-Codes

G-codes are CNC commands with a special syntax. The basic commands are implemented, extended commands can be emulated with BASIC subroutines. A G-code consists of a character immediately followed by a number. Some G-codes accept only integer numbers (n), some fix numbers (f) too.

G-codes use group 1 (see GROUP command) for movements. Group 1 must consist of 2 or 3 axes.

In each line, only one code of the types G00, G01, G02, G03 or G5n is allowed, another command, even separated by a colon is not possible. Numerical expressions or variables are not allowed as parameters, only simple integer or fix numbers.

#### Related commands and functions:

ON CODE(sel) GOTO|GOSUB, FMAX, CODE(sel), RESETCODEFLAGS, NEWCODE(sel), DEFAULTCODE, ON TOOLON GOTO|GOSUB, ON TOLOFF GOTO|GOSUB, TOOL

### Standard-G-Codes

#### Ff

##### Command

Sets the velocity for G01, G02 and G03, similar to the VEL command. A maximum value can be set with FMAX.

##### Syntax:

Ff

##### Example:

F50

G02 X20 Y50 F20

##### Similar:


FMAX, VEL

#### G00

##### Command

Position move to the given coordinates while using the parameters set by POSVEL, POSACC und POSDEC. Relative (G91) and absolute (G90) coordinates are possible as well as cartesian and polar coordinates (G09). Angles are given in degrees and angle=0° is the positive x axis. Positive angles are counterclockwise, negative angles clockwise.

If group 1 consists of 3 axes, the plane for the polar coordinates is defined by the given parameters, that means that only 2 of 3 possible coordinates can be used (e.g. I and J, J and K, K and I)



### Definitions:

Xf	X coordinate
Yf	Y coordinate
Zf	Z coordinate
Af	radius
Wf	angle
If	X coordinate of the center using polar coordinates or for circular movements
Jf	Y coordinate of the center using polar coordinates or for circular movements
Kf	Z coordinate of the center using polar coordinates or for circular movements
[...]	optional parameter

### Absolute cartesian coordinates:

X, Y and Z are the absolute target coordinates

#### Syntax:

G00 [G90] [Xf] [Yf] [Zf]

#### Example:

```
G00 X100 Z-50
G00 Y-14.5
G00 G90 X10.5
```

### Relative cartesian coordinates:

X, Y and Z are the coordinates of the target position relative to the last position.

#### Syntax:

G00 G91 [Xf] [Yf] [Zf]

#### Example:

```
G00 G91 X100 Z-50
G00 G91 Y-14.5
```

### Polar coordinates, absolute center, absolute angle:

I, J and K are the absolute center coordinates, W is the

absolute angle.

**Syntax:**

```
G00 G09 [M72] Af Wf [G90] If Jf      ` XY pl.
G00 G09 [M72] Af Wf [G90] Jf Kf     ` YZ pl.
G00 G09 [M72] Af Wf [G90] Kf If     ` ZX pl.
```

**Example:**

```
G00 G09 A50 W75 I50 J50
G00 G09 M72 A25.5 W33.34 I+20 K-10
```

**Polar coordinates, relative center, absolute angle:**

I, J and K are the coordinates of the center relative to the last position, W is the absolute angle.

**Syntax:**

```
G00 G09 [M72] Af Wf G91 If Jf      ` XY pl.
G00 G09 [M72] Af Wf G91 Jf Kf     ` YZ pl.
G00 G09 [M72] Af Wf G91 Kf If     ` ZX pl.
```

**Example:**

```
G00 G09 A50 W75 G91 I10 J10
G00 G09 M72 A25.5 W33.34 G91 I-20.3 J0
```

**Polar coordinates, absolute center, relative angle:**

I, J and K are the absolute center coordinates, W is the angle relative to the last angle.

**Syntax:**

```
G00 G09 M71 Af Wf [G90] If Jf      ` XY pl.
G00 G09 M71 Af Wf [G90] Jf Kf     ` XZ pl.
G00 G09 M71 Af Wf [G90] Kf If     ` ZX pl.
```

**Example:**

```
G00 G09 M71 A50 W15 I10 J10
G00 G09 M71 A25.5 W33.34 G90 I-20.3 J0
```

**Polar coordinates, relative center, relative angle:**

I, J and K are the coordinates of the center relative to the last position, W is the angle relative to the last angle.

**Syntax:**

```
G00 G09 M71 Af Wf G91 If Jf      ` XY pl.
G00 G09 M71 Af Wf G91 Jf Kf     ` YZ pl.
G00 G09 M71 Af Wf G91 Kf If     ` ZX pl.
```

**Example:**

```
G00 G09 M71 A50 W15 G91 I10 J10
G00 G09 M71 A25.5 W33.34 G91 I-20.3 J0
```

**Related commands and functions:**

POSACC, POSDEC, POSVEL, G01

## G01

### Command

Linear move to the given coordinates. Acceleration and deceleration are according to the values given with ACC and DEC. The velocity is set with the F-Code. A maximum value must be set with the FMAX command. The coordinate options are the same as for the G00 command.

**Related commands and functions:**  
ACC, DEC, VEL, FMAX, Ff, G00

**G02****Command**

Circular move clockwise to the given target coordinates. Acceleration and deceleration are according to the values given with ACC and DEC. The velocity is set with the F-Code. If group 1 has 3 axes, the selected coordinates define the plane in which the circular movement is performed, so only 2 of 3 coordinates can be used (e.g. I and J, J and K, K and I, resp. X and Y, Y and Z, Z and X).

**Definitions:**

Xf	X coordinate
Yf	Y coordinate
Zf	Z coordinate
Af	radius
Wf	angle
If	X coordinate of the center using polar coordinates or for circular movements
Jf	Y coordinate of the center using polar coordinates or for circular movements
Kf	Z coordinate of the center using polar coordinates or for circular movements
[...]	optional parameter

**absolute center, full circle:**

I, J and K define the center in absolute coordinates.

**Syntax:**

G02 [G90] If Jf	\ XY plane
G02 [G90] Jf Kf	\ YZ plane
G02 [G90] Kf If	\ ZX plane

**Example:**

```
G02 I-50 J50
G02 G90 I22.2 J22.2
```

**relative center, full circle:**

I, J and K define the center relative to the last position.

**Syntax:**

G02 G91 If Jf	\ XY plane
G02 G91 Jf Kf	\ YZ plane
G02 G91 Kf If	\ ZX plane

**Example:**

```
G02 G91 I-50 J50
G02 G91 I22.2 J22.2
```

**cartesian coordinates, absolute center:**

X, Y and Z define the target position in absolute coordinates. I, J and K define the center in absolute coordinates.

**Syntax:**

```
G02 Xf Yf [G90] If Jf          \ XY plane
G02 Yf Zf [G90] Jf Kf          \ YZ plane
G02 Zf Xf [G90] Kf If          \ ZX plane
```

**Example:**

```
G02 X10 Y10 I50 J50
G02 X-30 Y20 G90 I22.2 J22.2
```

**cartesian coordinates, relative center:**

X, Y and Z define the target position in absolute coordinates. I, J and K define the center relative to the last position.

**Syntax:**

```
G02 Xf Yf G91 If Jf          \ XY plane
G02 Yf Zf G91 Jf Kf          \ YZ plane
G02 Zf Xf G91 Kf If          \ ZX plane
```

**Example:**

```
G02 X10 Y10 G91 I-40 J50
G02 X-30 Y20 G91 I22.2 J22.2
```

**Polar coordinates, absolute center, absolute angle:**

Angle W is the final angle of the circular move, given as an absolute value. I, J and K define the center in absolute coordinates.

**Syntax:**

```
G02 G09 [M72] Wf [G90] If Jf          \ XY pl.
G02 G09 [M72] Wf [G90] Jf Kf          \ YZ pl.
G02 G09 [M72] Wf [G90] Kf If          \ ZX pl.
```

**Example:**

```
G02 G09 W100 I50 J50
G02 G09 M72 W-20 G90 I22.2 J22.2
```

**Polar coordinates, absolute center, relative angle:**

Angle W is the final angle of the circular move relative to the last angle. I, J and K define the center in absolute coordinates.

**Syntax:**

```
G02 G09 M71 Wf [G90] If Jf          \ XY pl.
G02 G09 M71 Wf [G90] Jf Kf          \ YZ pl.
G02 G09 M71 Wf [G90] Kf If          \ ZX pl.
```

**Example:**

```
G02 G09 M71 W100 I50 J50
G02 G09 M71 W-20 G90 I22.2 J22.2
```

**Polar coordinates, relative center, absolute angle:**

Angle W is the final angle of the circular move, given as an absolute value. I, J and K define the center relative to the last position.

**Syntax:**

```
G02 G09 [M72] Wf G91 If Jf          \ XY pl.
G02 G09 [M72] Wf G91 Jf Kf          \ YZ pl.
G02 G09 [M72] Wf G91 Kf If          \ ZX pl.
```

**Example:**

```
G02 G09 W100 G91 I50 J50
```

G02 G09 M72 W-20 G91 I22.2 J22.2

**Polar coordinates, relative center, relative angle:**

Angle W is the final angle of the circular move relative to the last angle. I, J and K define the center relative to the last position.

**Syntax:**

G02 G09 M71 Wf G91 If Jf \ XY-Eb.  
 G02 G09 M71 Wf G91 Jf Kf \ YZ-Eb.  
 G02 G09 M71 Wf G91 Kf If \ ZX-Eb.

**Example:**

G02 G09 M71 W100 G91 I50 J50  
 G02 G09 M71 W-20 G91 I22.2 J22.2

**Related commands and functions:**

FMAX, VEL, G03

**G03**

*Command*

Circular movement counterclockwise. Coordinates and syntax is like G02 command.

**Related commands and functions:**

FMAX, VEL, G02

**G53**

*Command*

Clear all coordinate shifting and rotating.

**Syntax:**

G53

**Related commands and functions:**

G54, G55, G56

**G54**

*Command*

Shifts the coordinate system independently from the SETPOS command. Valid only for G-codes. The actual position is now the position with coordinates X, Y and Z.

**Syntax:**

G54 Xf Yf Zf

**Related commands and functions:**

G53, G55, G56

**G55**

*Command*

Shifts and rotates the coordinate system independently from the SETPOS and TRAFO command. Valid only for G-codes. The coordinate system is rotated relatively by the angle W and shifted relatively by X, Y and Z.

**Syntax:**

G55 Xf Yf Zf Wf

**Related commands and functions:**

G53, G54, G56

**G56**

*Command*

Shifts and rotates the coordinate system independently from

the SETPOS and TRAFO command. Valid only for G-codes. The coordinate system is rotated absolutely to the angle  $w$  and shifted absolutely to the coordinates  $X$ ,  $Y$  and  $Z$ .

**Syntax:**

G56 Xf Yf Zf Wf

**Related commands and functions:**

G53, G54, G55

**M71***Command*

The angle in this line is a relative angle.

**Syntax:**

M71

**Related commands and functions:**

G00, G01, G02, G03

**M72***Command*

The angle in this line is an absolute angle.

**Syntax:**

M72

**Related commands and functions:**

G00, G01, G02, G03

**M80***Command*

Clears all mirror functions.

**Syntax:**

M80

**Related commands and functions:**

G53, G54, G55, G56, M81, M82, M83, M84

**M81***Command*

Sets the mirror function for  $Y$  axis, resp. changes sign of the  $X$  and  $I$  coordinates.

**Syntax:**

M81

**Related commands and functions:**

G53, G54, G55, G56, M80, M82, M83, M84

**M82***Command*

Sets the mirror function for  $X$  axis, resp. changes sign of the  $Y$  and  $J$  coordinates.

**Syntax:**

M82

**Related commands and functions:**

G53, G54, G55, G56, M80, M81, M83, M84

**M83***Command*

Sets the mirror function for  $XY$  plane, resp. changes sign of the  $Z$  and  $K$  coordinates.

**Syntax:**

M83

**Related commands and functions:**

G53, G54, G55, G56, M80, M81, M82, M84

**M84***Command*

Changes signs of the X and I coordinates and the Y and J coordinates.

**Syntax:**

M84

**Related commands and functions:**

G53, G54, G55, G56, M80, M81, M82, M83

**ON CODE***Command*

Sets the program line to which is jumped if the event CODE(sel) occurs. This event is caused by a G-Code with character sel (G, E (end of line), D, M, T)

**CODE (G)**

A G-Code is processed.

**CODE (E)**

The end of the command line is reached.

**CODE (D)**

A D-Code D is processed.

**CODE (M)**

A M-Code is processed.

**CODE (T)**

A T-Code is processed.

**Syntax:**

```
ON CODE(sel) GOTO|GOSUB n
```

**Example:**

```
..      Init
53110 ON CODE(G) GOSUB 72000
53120 ON CODE(E) GOSUB 73000
..
      main program
..
..      Event Subroutines
72000 '----- G-Code -----
72010 uv_sel=CODE(g)
72020 SELECT CASE uv_sel
72030   CASE 40: LED_1 ON: ' direkte Ausf.
72040   CASE 41: G41flag=1: ' indir. Ausf.
72100 END SELECT
72999 RETURN
73000 '----- EOL -----
73010 IF G41flag=1 THEN GOTO 74000: END IF
```

```
73999 RETURN
```

```
74000 '----- G41 -----
```

```
74010 IF NEWCODE(Z) THEN POSA 2, CODE(Z): END IF
```

```
74020 RESETCODEFLAGS
```

```
74999 RETURN
```

**Related commands and functions:**

ON, TOOLOFF, TOOLON

**Vn**

*Command*

Waits n seconds.

**Syntax:**

Vn

## 4. Appendix B: Programming hints for special hardware

### Programming of microstepping controllers:

The microstepping amplifiers in the controller models CO6100, CO6500 and CO6150 have to be programmed with the desired current profile. In general a sine and cosine profile is used. Two arrays of fix values and a length of 256 are filled with the appropriate values of a full cycle (4 full steps). A resolution of 1/64 step can be obtained. The current values have to be between -1 and +1 for CO6100 and CO6500 and between 0 and 1 for CO6150.

The profile for phase 1 is programmed with `SET na,WAVEFORM1,sinarray[0]`, for phase two with `SET na,WAVEFORM2,cosarray[0]`. The current polarity is programmable unrestrictedly for CO6100 and CO6500, but predefined for CO6150. With CO6150 `waveform1` is positive from 1 to 128 and negative from 129 to 256 (sine). `waveform2` is positive from 1 to 64 and from 193 to 256, and negative from 65 to 192 (cosine).

The phase current can be calculated from the programmed array value multiplied with the maximum amplifier current multiplied with the percentage given by `SET na,IMAX,a` und `SET na,ISTANDBY,a`. Maximum current for CO6100 and CO6500 is 4 A. Maximum current for CO6150 can be set with a potentiometer from 1.2 A to 4.8 A. For thermal reasons 3 A should not be exceeded in the long run.

Example for CO6100 and CO6500:

```
MODE 1,SM,STEPDIR(1)
DIM sinwave(256) AS FIX
DIM coswave(256) AS FIX
FOR i = 1 TO 256: sinwave(i)=SIN((i-1)*2*PI/256): NEXT
FOR i = 1 TO 256: coswave(i)=COS((i-1)*2*PI/256): NEXT
SET 1,WAVEFORM1,sinwave(0)
SET 1,WAVEFORM2,coswave(0)
SET 1,ISTANDBY,40
SET 1,IMAX,70
```

Example for CO6150:

```
MODE 1,SM,STEPDIR(1)
DIM sinwave(256) AS FIX
DIM coswave(256) AS FIX
FOR i = 1 TO 256: sinwave(i)=ABS(SIN((i-1)*2*PI/256)): NEXT
FOR i = 1 TO 256: coswave(i)=ABS(COS((i-1)*2*PI/256)): NEXT
SET 1,WAVEFORM1,sinwave(0)
SET 1,WAVEFORM2,coswave(0)
SET 1,ISTANDBY,40
SET 1,IMAX,70
```

More axes can share the same array. For precision moves `IMAX` and `ISTANDBY` should be the same.

### Programming hints for CO6300

The amplifiers of CO6300 have preprogrammed current profiles (sine and cosine,

contact factory for other profiles). An array is not necessary. The resolution is 128 steps per full phase, which corresponds to a resolution of 1/32 step.

Programming example for CO6300:

```
MODE 1, SM, STEPDIR(1)
SET 1, ISTANDBY, 40
SET 1, IMAX, 70
```

## Amplifier PW2000


The servo amplifier PW2000 is a PWM amplifier with current monitoring. The average maximum current is limited to the value set with `SET na, IMAX` (% of 10 A). For a certain time (set with trimmer T) the current can be greater than `IMAX`, but is limited to the value set with `SET na, IPEAK` (% of 20 A). Don't use values greater than 90% for `IPEAK`. In case of a short circuit the amplifier is switched off. The error mode can be reset by the `MOTOR na OFF` command followed by `MOTOR na ON`.

PWM frequency:	ca. 20 kHz
max. amplifier voltage:	42 V DC
max. peak motor current:	18 A
max. average motor current:	10 A

Motor supply and controller supply are separated galvanically.

Configuration parameters:

PWM polarity:	<code>SET na, PWMPOL, TRUE</code>
max average current:	<code>SET na, IMAX, a</code> a=0..100, 100 corresponds to 10 A
max. peak current:	<code>SET na, IPEAK, a</code> a=0..90, 90 corresponds to 18 A



**Jogdial programming**

The jogdial is connected to an incremental decoder. The position is read in during a timer routine and cursor-up and cursor-down character sequences are generated. The character sequence for cursor-up is ESC [ A and for cursor-down ESC [ B. The keyboard device can be opened for writing and characters written to the devices can immediately read back from the device, e.g. while using the GETFILENAME\$ function.

The following program generates one cursor-up resp. one cursor-down sequence every four increments.

**Initializing:**

```

950 OPEN "KEY:" FOR OUTPUT AS #2
960 wheelscale=4
970 wheelpos=INC(1)/wheelscale
980 lastwheelpos=INC(1)/wheelscale
990 wheelflag=0
1000 ON TIMER(50) GOSUB 20000: TIMER ON
1010 ...
    
```

**Activate for a menu selection:**

```
3000 wheelflag=1
3010 menselect=MENU("CONFIG",menlist(0))
3020 wheelflag=0
```

**Timer subroutine:**

```
20000 '----- TIMER -----
20010 IF wheelflag=0 THEN GOTO 20200: END IF
20020 wheelpos=INC(1)/wheelscale
20030 wheeldiff=wheelpos-lastwheelpos
20040 IF wheeldiff<0 THEN GOTO 20120: END IF
20050 wheeldiff=CINT(wheeldiff-0.010)
20060 IF wheeldiff=0 THEN GOTO 20200: END IF
20070 lastwheelpos=wheelpos
20080 FOR i=1 TO wheeldiff
20090   PRINT #2,CHR$(27);CHR$(91);CHR$(65);
20100 NEXT i
20110 GOTO 20200
20120 wheeldiff=CINT(ABS(wheeldiff)-0.010)
20130 IF wheeldiff=0 THEN GOTO 20200: END IF
20140 lastwheelpos=wheelpos
20150 FOR i=1 TO wheeldiff
20160   PRINT #2,CHR$(27);CHR$(91);CHR$(66);
20170 NEXT i
20200 ' other timer subroutines
20210 ...
20900 RETURN
```

## 5. Appendix C: Inputs and outputs

### Inputs

#	CO2200	CO4200	CO6100	CO6500	CO5400
1	IN1	IN1 (1)	IO1	IO1	IN1 (1)
2	IN2	IN2 (1)	IO2	IO2	IN2 (1)
3	IN3	IN3 (1)	IO3	IO3	IN3 (1)
4	IN4	IN4 (1)	IO4	IO4	IN4 (1)
5	IN5	IN5 (1)	IO5	IO5	IN5 (1)
6	IN6	IN6 (1)	IO6	IO6	IN6 (1)
7	IN7	IN7 (1)	IO7	IO7	IN7 (1)
8	IN8	IN8 (1)	IO8	IO8	IN8 (1)
9	IO1	IN9 (2)	IN9	IN9	REF1 (2)
10	IO2	IN10 (2)	IN10	IN10	REF2 (2)
11	IO3	IN11 (2)	IN11	IN11	REF3 (2)
12	IO4	IN12 (2)	IN12	IN12	REF4 (2)
13	IO5	IN13 (2)	IN13	IN13	S+ (2)
14	IO6	IN14 (2)	IN14	IN14	FAULT1 (2)
15	IO7	IN15 (2)	IN15	IN15	FAULT2 (2)
16	IO8	IN16 (2)	IN16	IN16	EXT (2)
17	PI0	IN17 (3)			INDEX1 (3)
18	PI1	IN18 (3)			INDEX2 (3)
19	PI2	IN19 (3)			INDEX3 (3)
20	PI3	IN20 (3)			
21	ERROR1	ERROR1			
22	ERROR2	ERROR2			
23	ERROR3	ERROR3			
24	S+	ERROR4			
25		INDEX1 (4)			
26		INDEX2 (4)			
27		INDEX3 (4)			
28		INDEX4 (4)			
29		-			
30		-			
31		-			
32		-			
33		PI0 (5)			
34		PI1 (5)			
35		PI2 (5)			
36		PI3 (5)			

#	CO2200	CO4200	CO6100	CO6500	CO5400
37		FAULT (5)			
38		S+ (5)			

















## Outputs

#	CO2200	CO4200	CO6100	CO6500	CO5400
1	IO1	OUT1 (1)	IO1	IO1	OUT1 (1)
2	IO2	OUT2 (1)	IO2	IO2	OUT2 (1)
3	IO3	OUT3 (1)	IO3	IO3	OUT3 (1)
4	IO4	OUT4 (1)	IO4	IO4	OUT4 (1)
5	IO5	OUT5 (1)	IO5	IO5	OUT5 (1)
6	IO6	OUT6 (1)	IO6	IO6	OUT6 (1)
7	IO7	OUT7 (1)	IO7	IO7	OUT7 (1)
8	IO8	OUT8 (1)	IO8	IO8	OUT8 (1)
9		OUT9 (2)			OUT9 (2)
10		OUT10 (2)			OUT10 (2)
11		OUT11 (2)			OUT11 (2)
12		OUT12 (2)			OUT12 (2)
13		OUT13 (2)			
14		OUT14 (2)			
15		OUT15 (2)			
16		OUT16 (2)			
17					
18					
19					
20					
21					
22					
23					
24					


## 6. Appendix D: ASCII code table

Code	Char	Key	Function	Code	Char	Code	Char	Code	Char
0	Ctrl-A			32	SPACE	64	@	96	`
1	Ctrl-B			33	!	65	A	97	a
2	Ctrl-C			34	"	66	B	98	b
3	Ctrl-D	STOP	BREAK	35	#	67	C	99	c
4	Ctrl-E	HALT		36	\$	68	D	100	d
5	Ctrl-F	EDIT		37	%	69	E	101	e
6	Ctrl-G	START		38	&	70	F	102	f
7	Ctrl-H	RUN		39	'	71	G	103	g
8	Ctrl-I	DEL		40	(	72	H	104	h
9	Ctrl-J		TAB	41	)	73	I	105	i
10	Ctrl-J		LF	42	*	74	J	106	j
11	Ctrl-K			43	+	75	K	107	k
12	Ctrl-L		FF	44	,	76	L	108	l
13	Ctrl-M		CR	45	-	77	M	109	m
14	Ctrl-N	MENU		46	.	78	N	110	n
15	Ctrl-O	MOVE		47	/	79	O	111	o
16	Ctrl-P	STEP		48	0	80	P	112	p
17	Ctrl-Q		XON	49	1	81	Q	113	q
18	Ctrl-R	REF		50	2	82	R	114	r
19	Ctrl-S		XOFF	51	3	83	S	115	s
20	Ctrl-T	TEACH		52	4	84	T	116	t
21	Ctrl-U			53	5	85	U	117	u
22	Ctrl-V			54	6	86	V	118	v
23	Ctrl-W			55	7	87	W	119	w
24	Ctrl-X			56	8	88	X	120	x
25	Ctrl-Y			57	9	89	Y	121	y
26	Ctrl-Z			58	:	90	Z	122	z
27		ESC	ESC	59	;	91	[	123	{
28				60	<	92	\	124	
29				61	=	93	]	125	}
30				62	>	94	^	126	~
31				63	?	95	_	127	

### 7. Appendix E: Pinouts



# NOTAUSKREIS CO2200, CO4300



## 8. Appendix F: Pin description

Name	Function
+24V	24 VDC power supply
+5V	+5 VDC power output to supply amplifiers and incremental encoders
AGND	analogue ground
AIN	analogue input +/-10V
AOUT	analogue output +/-10V
CANH, CANL	CAN bus, external termination
C-GND	CAN ground
CHA+, CHA-	differential inputs, 120Ω termination, incremental encoder channel A
CHB+, CHB-	differential inputs, 120Ω termination, incremental encoder channel B
CHI+, CHI-	differential inputs, 120Ω termination, incremental encoder channel Index
CTS	RS232 Clear To Send
CTS+, CTS-	RS422 Clear To Send, differential inputs, 120Ω termination
DA-A	analogue output 0..5V, amplifier current control
DA-B	analogue output 0..5V, amplifier current control
EIN1, EIN2	internal EIN relay, emergency stop circuit
EN	amplifier enable output, 0V = Off, +5V = On
ERR	error input, convention: 0V = OK, +5V = ERROR
GND	ground
IN, REF	24 V input, ca. 4 mA input current
IO	24 V input/output, output current max. 350 mA (source driver) if used as input, set pin to 0 (PINOUT n, 0)
NOTAUS1, NOTAUS2	External emergency stop circuit
OUTn	24 V output, output current max. 350 mA (source driver)
PA	Stepper motor controller phase A, resp. direction
PB	Stepper motor controller phase B, resp. step
PC	Stepper motor controller phase C, resp. standby/max
PD	Stepper motor controller phase D
PWM	PWM output (5V)
RTS	RS232 Ready To Send
RTS+, RTS-	RS422 Ready To Send, differential outputs
RXD	RS232 receive data
RXD+, RXD-	RS422 receive data, differential inputs, 120Ω termination
SCHÜTZ+	Emergency stop circuit, sense input
SIGN	SIGN output (5V)
TXD	RS232 transmit data
TXD+, TXD-	RS422 transmit data, differential outputs